

# 304


-001  
thru  
-016

**Ritter®**  
by MIDMARK

## Examination Table

Serial Number Prefixes:  
GJ, GK, GL, JE, JF, JG  
JH, KV, KW, KX, KZ & LC

## Service and Parts Manual



**304** -001  
thru  
-016

MA360200

FOR USE BY MIDMARK  
TRAINED TECHNICIANS ONLY

SF-1532

Part No. 004-0044-00 Rev. I (1/01/04)



**TABLE OF CONTENTS**

**Section/Paragraph.....Page**

**IMPORTANT INSTRUCTIONS**

|                                   |    |
|-----------------------------------|----|
| General Safety Instructions ..... | ii |
| Safety Alert Symbols .....        | ii |
| Warranty Instructions .....       | ii |

**SECTION I GENERAL INFORMATION**

|                                         |     |
|-----------------------------------------|-----|
| 1.1 Scope of Manual .....               | 1-1 |
| 1.2 How to Use Manual .....             | 1-1 |
| 1.3 Description Of 304 Exam Table.....  | 1-1 |
| 1.4 Standard Torque Specifications..... | 1-2 |
| 1.5 Specifications .....                | 1-3 |
| 1.6 Parts Replacement Ordering.....     | 1-3 |
| 1.7 Special Tools .....                 | 1-5 |

**SECTION II TESTING AND TROUBLESHOOTING**

|                                             |     |
|---------------------------------------------|-----|
| 2.1 Operational Test (See Figure 2-1) ..... | 2-1 |
| 2.2 Troubleshooting Procedures .....        | 2-3 |

**SECTION III SCHEDULED MAINTENANCE**

|                                 |     |
|---------------------------------|-----|
| 3.1 Scheduled Maintenance ..... | 3-1 |
|---------------------------------|-----|

**SECTION IV MAINTENANCE/SERVICE INSTRUCTIONS**

|                                                                                   |      |
|-----------------------------------------------------------------------------------|------|
| 4.1 Introduction.....                                                             | 4-1  |
| 4.2 Styled Upholstery Removal /<br>Installation .....                             | 4-1  |
| 4.3 Soft Touch Upholstery<br>Removal / Installation.....                          | 4-2  |
| 4.4 Footrest Extension Removal /<br>Installation .....                            | 4-4  |
| 4.5 Step Assembly Removal /<br>Installation .....                                 | 4-5  |
| 4.6 Back Lock Assembly Removal /<br>Installation .....                            | 4-7  |
| 4.7 Lift Lever Removal / Installation .....                                       | 4-9  |
| 4.8 Heater ON / OFF Switch<br>Removal / Installation.....                         | 4-11 |
| 4.9 Heater Plate Removal /<br>Installation .....                                  | 4-12 |
| 4.10 Stirrup Components Removal /<br>Installation .....                           | 4-13 |
| 4.11 Electrical Receptacle Removal /<br>Installation (120 VAC units).....         | 4-15 |
| 4.12 Typical Electrical Receptacle Removal /<br>Installation (220 VAC units)..... | 4-16 |

**Section/Paragraph ..... Page**

|                                                              |      |
|--------------------------------------------------------------|------|
| 4.13 Fuse Removal / Installation<br>(220 VAC units).....     | 4-18 |
| 4.14 AC Inlet Removal / Installation<br>(220 VAC units)..... | 4-19 |

**SECTION V SCHEMATICS AND DIAGRAMS**

|                                                      |     |
|------------------------------------------------------|-----|
| 5.1 Electrical Schematics /<br>Wiring Diagrams ..... | 5-1 |
|------------------------------------------------------|-----|

**SECTION VI PARTS LIST**

|                                                                |        |
|----------------------------------------------------------------|--------|
| 6.1 Introduction .....                                         | 6-1    |
| 6.2 Description Of Columns .....                               | 6-1    |
| 6.3 Torque Specifications And Important<br>Assembly Notes..... | 6-1    |
| Pictorial Index .....                                          | 6-2.*  |
| Table Top Components<br>(Vacu-Form upholstery) .....           | 6-3.*  |
| Table Top Components<br>(Soft Touch upholstery).....           | 6-4    |
| Upperwrap Components .....                                     | 6-5.*  |
| Stirrup Components .....                                       | 6-6.*  |
| Cabinet Components<br>(120 VAC units).....                     | 6-7    |
| Cabinet Components<br>(220 VAC units).....                     | 6-8    |
| Step Assembly .....                                            | 6-9    |
| Electrical Components<br>(120 VAC units).....                  | 6-10.* |
| Electrical Components<br>(220 VAC units).....                  | 6-11.* |
| Receptacle Assembly<br>(220 VAC units).....                    | 6-12   |

|                     |     |
|---------------------|-----|
| COMMENTS .....      | 7-1 |
| FAX ORDER FORM..... | 7-2 |

(\*) Indicates that there has been a serial number break for the illustration and that there are additional point page(s) following the original page.

# TABLE OF CONTENTS

## General Safety Instructions

**Safety First:** The primary concern of Midmark Corporation is that this table is maintained with the safety of the patient and staff in mind. To assure that services and repairs are completed safely and correctly, proceed as follows:

- (1) Read this entire manual before performing any services or repairs on this table.
- (2) Be sure you understand the instructions contained in this manual before attempting to service or repair this table.

## Safety Alert Symbols

Throughout this manual are safety alert symbols that call attention to particular procedures. These items are used as follows:



### DANGER

A **DANGER** is used for an imminently hazardous operating procedure, practice, or condition which, if not correctly followed, will result in loss of life or serious personal injury.



### WARNING

A **WARNING** is used for a potentially hazardous operating procedure, practice, or condition which, if not correctly followed, could result in loss of life or serious personal injury.



### CAUTION

A **CAUTION** is used for a potentially hazardous operating procedure, practice, or condition which, if not correctly followed, could result in minor or moderate injury. It may also be used to alert against unsafe practices.



### EQUIPMENT ALERT

An **EQUIPMENT ALERT** is used for an imminently or potentially hazardous operating procedure, practice, or condition which, if not correctly followed, will or could result in serious, moderate, or minor damage to unit.

## NOTE

A **NOTE** is used to amplify an operating procedure, practice or condition.

## Warranty Instructions

Refer to the Midmark "Limited Warranty" printed in the Installation and Operation Manual for warranty information. Failure to follow the guidelines listed below will void the warranty and/or render the 304 Medical Examination Table unsafe for operation.

- In the event of a malfunction, do not attempt to use the examination table until necessary repairs have been made.
- Do not attempt to disassemble table, replace malfunctioning or damaged components, or perform adjustments unless you are one of Midmark's authorized service technicians.
- Do not substitute parts of another manufacturer when replacing inoperative or damaged components. Use only Midmark replacement parts.

SECTION I  
GENERAL INFORMATION**1.1 Scope of Manual**

This manual contains detailed troubleshooting, scheduled maintenance, maintenance, and service instructions for the 304 Medical Examination Table. This manual is intended to be used by Midmark's authorized service technicians.

**1.2 How to Use Manual****A. Manual Use When Performing Scheduled Maintenance.**

- (1) Perform inspections and services listed in Scheduled Maintenance Chart (Refer to para 3.1).
- (2) If a component is discovered to be faulty or out of adjustment, replace or adjust component in accordance with maintenance / service instructions (Refer to para 4.1).

**B. Manual Use When Unit Is Malfunctioning And Cause Is Unknown.**

- (1) Perform an operational test on table (Refer to para 2.1).
- (2) Perform troubleshooting procedures listed in Troubleshooting Guide (Refer to para 2.2).
- (3) If a component is discovered to be faulty or out of adjustment, replace or adjust component in accordance with maintenance / service instructions (Refer to para 4.1).

**C. Manual Use When Damaged Component Is Known.**

- (1) Replace or adjust component in accordance with maintenance / service instructions (Refer to para 4.1).

**1.3 Description Of Model 304 Medical Examination Table****A. General Description (See Figure 1-1).**

The Model 304 Series Medical Examination Table is primarily used in examination rooms for general examinations and minor procedures. The table top is adjustable

from a full horizontal position to a chair position. Also, when supported with an optional pelvic lift bar, the lithotomy position can be achieved. There are five storage drawers which accommodate supplies used during examinations. Listed below are the models currently available:

---

|                                                |               |
|------------------------------------------------|---------------|
| 304 (-001 thru -004 &<br>-007 thru -014) ..... | 120 VAC units |
| 304 (-005, -006, -015, -016) .....             | 220 VAC units |

---

The major serviceable components of the table are the drawer heater plate (optional) (1, Figure 1-1), heater ON / OFF switch (optional) (2), electrical receptacle (3, 120 VAC model shown), back lock assembly (4), lift assembly (5), step assembly (6), and two stirrup assemblies (7).

**B. Model 304 Theory of Operation (120 VAC Units)  
(See Figure 5-1 for wiring diagram / electrical schematic)**

Line voltage (120 VAC) is supplied thru the power cord to electrical receptacles located on the side of the table. As long as the power cord is plugged into a supply outlet, 120 VAC power will be present at the receptacles.


Optional Heater Plate:

Some units are equipped with the optional heater plate for drawer warming. When the operator turns the (N.O.) heater ON / OFF switch to ON, closing the circuit, power is supplied to the heater plate, heating the unit. This provides heat in the top, foot end drawer to warm instruments.

**C. Model 304 Theory of Operation (220 VAC Units)  
(See Figure 5-2 for wiring diagram / electrical schematic)**

Line voltage (220 VAC) is supplied thru the power cord to the AC inlet located on the base of the table. From the AC inlet, voltage is supplied to the receptacle located on the side of the table. As long as the power cord is plugged into a supply outlet, 220 VAC power will be present at the receptacle.

## SECTION I GENERAL INFORMATION



MA356100

**Figure 1-1. Major Components**

### Optional Heater Plate:

Some units are equipped with the optional heater plate for drawer warming. When the operator turns the (N.O.) heater ON / OFF switch to ON, closing the circuit, power is supplied to the heater plate, heating the unit. This provides heat in the top, foot end drawer to warm instruments.

## 1.4 Standard Torque Specifications

The following standard torque specifications in Table 1-1 apply to the hardware used on the unit unless otherwise listed elsewhere in the service procedures or parts illustrations:

**Table 1-1. Torque Specifications**

| Hardware Size  | Torque Values                          |
|----------------|----------------------------------------|
| #6 .....       | 11 to 21 inch / lbs. (1.2 to 2.3 N•M)  |
| #8 .....       | 20 to 30 inch / lbs. (2.2 to 3.3 N•M)  |
| #10 .....      | 32 to 42 inch / lbs. (3.6 to 4.8 N•M)  |
| 1/4 inch.....  | 75 to 85 inch / lbs. (8.5 to 9.6 N•M)  |
| 5/16 inch..... | 18 to 22 ft. / lbs. (24.4 to 29.8 N•M) |
| 3/8 inch.....  | 31 to 35 ft. / lbs. (42.0 to 47.5 N•M) |
| 1/2 inch.....  | 50 to 60 ft. / lbs. (67.8 to 81.4 N•M) |

### 1.5 Specifications

Factual data for the 304 Examination Table is provided in Table 1-2. Also, see Figure 1-2.

**Table 1-2. Specifications**

| Description                                                | Data                                         |
|------------------------------------------------------------|----------------------------------------------|
| Weight of a Unit:                                          |                                              |
| Without Shipping Carton .....                              | 250 lbs (113.4 kg)                           |
| With Shipping Carton .....                                 | 300 lbs (136 kg)                             |
| Shipping Carton: .....                                     | 60.5 in. "L" x 30 in. "W" x 42 in. "H"       |
|                                                            | (153.7 cm x 76.2 cm x 106.7 cm)              |
| Dimensions (See Figure 1-2):                               |                                              |
| Table Top Length .....                                     | 56 in. (142.24 cm)                           |
| Table Top Length (footrest extended) .....                 | 74 in. (188 cm)                              |
| Table Top Width .....                                      | 27 in. (68.6 cm)                             |
| Overall Width .....                                        | 27 in. (68.6 cm)                             |
| Seat Height (to top of upholstered seat at foot end) ..... | 32.125 in. (81.6 cm)                         |
| Table Adjustment:                                          |                                              |
| Back Section .....                                         | 0° to 65°                                    |
| Weight Capacity (Maximum) .....                            | 325 lbs. (147.4 kg)                          |
| Electrical Requirements:                                   |                                              |
| 304(-001 thru -004 & -007 thru -010) .....                 | 110-120 VAC, 60 HZ, 1.25 amp, single phase   |
| 304(-005, -006, -015, -016) .....                          | 220-240 VAC, 50/60 HZ, 5 amp, single phase   |
| Power Consumption:                                         |                                              |
| 304 (-001 thru -004 & -007 thru -010) .....                | 115 VAC @ 6 amps= 690 Watts (without heater) |
|                                                            | 115 VAC @ 6.5 amps= 748 Watts (with heater)  |
| 304 (-005, -006, -015, -016) .....                         | 230 VAC @ 5 amps= 1150 Watts                 |
| Fuse Rating:                                               |                                              |
| 304 (-005, -006, -015, -016) .....                         | 6.3 amp, 250 VAC 5 x 20mm, Type Slo-Blo      |

### 1.6 Parts Replacement Ordering

If a replacement part is required, order the part directly from the factory as follows:

- (1) Refer to Figure 1-3 to determine the location of the model number and serial number of the table and record this data.
- (2) Refer to the Parts List to determine the item numbers of the parts, part numbers of the parts, descriptions of the parts, and quantities of parts needed and record this data (Refer to para 6.1).

#### NOTE

Ask the Purchasing Department of the company that owns the table for this information. Otherwise, this information may be obtained from the dealer that sold the table.

- (3) Determine the installation date of the table and record this data. Call Midmark with the recorded information and ask for the Medical Products Technical Services Department. See back cover of this manual for the phone number or use the Fax Order Form (See page 7-2 for Fax Order Form).




## SECTION I GENERAL INFORMATION

### 1.7 Special Tools

Table 1-3 lists all of the special tools needed to repair the table, how to obtain the special tools, and the purpose of each special tool.

**Table 1-3. Special Tool List**

| Description of Special Tool | Manufacturer's Name / Address / Phone | Manufacturer's Part Number              | Purpose of Special Tool                             |
|-----------------------------|---------------------------------------|-----------------------------------------|-----------------------------------------------------|
| Multimeter                  | Commercially Available                | Any Type                                | Used to perform continuity and voltage checks.      |
| Pop Rivet Gun               | Commercially Available                | For installation of 1/8 in. pop rivets. | For installation of drawer slides and mullions.     |
| Torque Wrench               | Commercially Available                | Any Type                                | Used to tighten nuts or screws to specified values. |



MA364000

**Figure 1-3. Model Number / Serial Number Location**

## **SECTION I GENERAL INFORMATION**

## SECTION II TESTING AND TROUBLESHOOTING

### SECTION II TESTING AND TROUBLESHOOTING

#### 2.1 Operational Test (See Figure 2-1)

In order to effectively diagnose a malfunction of the table, it may be necessary to perform an operational test as follows:



#### WARNING

Refer to the Operator Manual for complete instructions on operating the examination table. Failure to do so could result in personal injury.

#### NOTE

The Operational Test, for the most part, only describes what should happen when the table is operated. If the table does something other than described, a problem has been discovered. Refer to the Troubleshooting Guide to determine the cause of the problem and its correction.

- (1) Plug the table power cord into a grounded, non-isolated, correctly polarized outlet, that has the proper voltage for the table.
- (2) Using a multimeter, check for proper voltage at the table's electrical receptacle (1).

**Observe.** For 304 (-001 thru -004 & -007 thru -014): There should be 120 VAC present at the receptacle. For 304 (-005, -006, -015, -016): There should be 220 VAC present at the receptacle.

- (3) If the unit has the optional heater, turn the heater ON / OFF switch (2) to ON.

**Observe.** The heater ON / OFF switch (2) should illuminate and the heater plate should begin to warm the top drawer at the foot end of the table (9).

Turn the heater ON / OFF switch (2) to OFF.

- (4) Pull footrest assembly (3) out all the way.

**Observe.** The footrest assembly should extend easily. The footrest assembly should hit stops at the end of its travel, preventing accidental removal.

- (5) Lift up on the head board assembly (4) stopping at several positions.

**Observe.** The head board assembly (4) should raise smoothly. The back support rod and lock assembly should hold the head board firmly at all positions without slipping. The head board should be able to be raised to 80°.

#### NOTE

The head board assembly should hold firmly with a 200 lb. (90.7 kg) load applied to the head end of the table.

- (6) Apply pressure to the head board assembly (4) to check for drifting. Then press down on one of the back lock handles (5) while pressing down on the head board assembly and lower the head board all the way down.

**Observe.** The back lock assembly should not drift when pressure is applied to head board assembly. The back lock rod assembly should retract smoothly without binding when back lock handles are depressed. The head board assembly should be able to be lowered to a horizontal position.


- (7) On units with the optional pelvic tilt, lift up on the seat section (6) slightly.

**Observe.** The pelvic lift bar (7) should automatically raise up into its locked position, supporting the seat section in the pelvic lift position (+5° above horizontal).

To lower the seat section (6) to standard position, raise up slightly on seat section; then grasp the pelvic lift bar (7) and rotate it downward while lowering the seat section.

- (8) Extend the stirrups (8); then lift up on the end of each stirrup and move them laterally. Let the stirrups lock into each of the four positions. While applying downward pressure, attempt to move each stirrup to the left and to the right.

## SECTION II TESTING AND TROUBLESHOOTING



MA380600

**Figure 2-1. Operational Test**

**Observe.** The stirrups (8) should slide out easily and move freely from left to right when raised. The stirrups should lock into each of the four positions and should not move laterally as long as downward pressure is applied.

(9) Check operation of each drawer (9).

**Observe.** The drawers should slide out easily. All drawer rollers should move freely in the drawer tracks.

(10) Check operation of step (10).

**Observe.** The step (10) should pull out easily. The step should drop into locked position when it is fully extended and should not pull out of the table.

## SECTION II

### TESTING AND TROUBLESHOOTING

## 2.2 Troubleshooting Procedures

Table 2-1 is a Troubleshooting Guide which is used to determine the cause of the malfunction.

| Problem                                                              | Symptom                                                                                                                  | Probable Cause                                                        | Check                                                                                                                                                                          | Correction                                                                                                                                   |
|----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Drawer warmer is not working. Power is present at the supply outlet. | Heater plate assembly does not warm up when heater ON / OFF switch is turned ON.                                         | Heater ON / OFF switch is malfunctioning.                             | When heater ON / OFF switch is turned to ON, heater switch should illuminate (this indicates that there is power present at output terminals of switch).                       | If heater ON / OFF switch does not illuminate when turned ON, replace heater switch. Refer to para 4.8.                                      |
|                                                                      |                                                                                                                          | Heater plate assembly is malfunctioning                               | Replace suspect heater plate assembly with known working heater plate assembly or check for continuity thru heater plate assembly wires.                                       | Replace heater plate assembly. Refer to para 4.9.                                                                                            |
|                                                                      |                                                                                                                          | Wire connections are loose.                                           | Check all wiring connections from power heater ON / OFF switch to heater plate assembly. Perform continuity check on wires. Use multimeter to check for proper voltage levels. | Clean any dirty connections. Tighten any loose connections. Replace any damaged connections. Refer to para 5.1.                              |
| Electrical receptacle is not working.                                | Table power cord is plugged into wall outlet and power is present, but there is still no power at electrical receptacle. | Electrical receptacle is malfunctioning.                              | Replace suspect electrical receptacle with known working receptacle.                                                                                                           | Replace electrical receptacle. <b>120 VAC Units:</b> Refer to para 4.11. <b>220 VAC Units:</b> Refer to para 4.12.                           |
|                                                                      |                                                                                                                          | Wire connections are loose.                                           | Check all wiring connections from power cord to electrical receptacle. Perform continuity check on wires. Use multimeter to check for proper voltage levels.                   | Clean any dirty connections. Tighten any loose connections. Replace any damaged connections. Refer to para 5.1.                              |
|                                                                      |                                                                                                                          | Line fuse(s) blown (applies to 220 VAC units only).                   | Perform continuity check on fuses.                                                                                                                                             | Replace fuse(s). Refer to para 4.13.                                                                                                         |
|                                                                      |                                                                                                                          | AC inlet is malfunctioning (applies to 220 VAC units only).           | Replace suspect AC inlet with known working AC inlet.                                                                                                                          | Replace AC inlet. Refer to para 4.14.                                                                                                        |
| Electrical receptacle or optional drawer warmer not working.         | No power is available at electrical receptacle and heater ON / OFF switch does not illuminate when pressed.              | Power cord is not plugged into facility wall outlet.                  | Check to see if power cord is plugged in.                                                                                                                                      | Plug power cord into facility wall outlet.                                                                                                   |
|                                                                      |                                                                                                                          | Facility circuit breaker providing power to table is tripped / blown. | Check to see if facility circuit breaker is tripped / blown. One way of checking this is to plug a lamp into wall outlet that table was plugged into.                          | If circuit breaker is tripped, determine what caused circuit breaker to trip, correct the problem, and then reset / replace circuit breaker. |

## SECTION II

### TESTING AND TROUBLESHOOTING

| Problem                                                                 | Symptom                                                                                                                | Probable Cause                                                                                                        | Check                                                                                                                                                                                   | Correction                                                                                                      |
|-------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
| Electrical receptacle or optional drawer warmer not working. -Continued | No power is available at electrical receptacle and heater ON / OFF switch does not illuminate when pressed. -Continued | Wire connections are loose.                                                                                           | Check all wiring connections from power cord to electrical receptacle and heater ON / OFF switch. Perform continuity check on wires. Use multimeter to check for proper voltage levels. | Clean any dirty connections. Tighten any loose connections. Replace any damaged connections. Refer to para 5.1. |
|                                                                         |                                                                                                                        | Line fuse(s) blown (applies to 220 VAC units only).                                                                   | Perform continuity check on fuses.                                                                                                                                                      | Replace fuse(s). Refer to para 4.13).                                                                           |
|                                                                         |                                                                                                                        | AC inlet is malfunctioning (applies to 220 VAC units only).                                                           | Replace suspect AC inlet with known working AC inlet.                                                                                                                                   | Replace AC inlet. Refer to para 4.14.                                                                           |
| Head Board Assembly does not operate correctly.                         | Head Board will not stay in position, drifts down.                                                                     | Springs on back lock assembly have broken or come loose.                                                              | Check condition of the back lock springs.                                                                                                                                               | Replace the springs on the back lock assembly. Refer to para 4.6.                                               |
|                                                                         | Headboard will not stay in position, drifts down (continued).                                                          | The hole in the back lock assembly for the back support rod has worn or elongated.                                    | Check the condition of the back lock assembly for excessive wear.                                                                                                                       | Replace the back lock assembly. Refer to para 4.6.                                                              |
|                                                                         |                                                                                                                        | The back support rod has worn excessively and will not hold in the back lock assembly.                                | Check for excessive wear on the back support rod.                                                                                                                                       | Replace the back support rod. Refer to para 4.6.                                                                |
|                                                                         | Head Board will not descend when back lock handle(s) are depressed.                                                    | Back lock springs are disconnected or broken.                                                                         | Inspect the back lock springs.                                                                                                                                                          | Connect and / or replace the back lock springs. Refer to para 4.6.                                              |
|                                                                         |                                                                                                                        | Back support rod out of alignment causing the rod to bind in the back lock assembly.                                  | Check the alignment of the back support rod and insure the screws are tight on the back support plate or bracket.                                                                       | Re-align the back support rod plate or bracket and tighten the mounting screws. Refer to para 4.6.              |
|                                                                         |                                                                                                                        | Set screws that secure the back lock assembly to the back lock rod are loose or missing.                              | Check the set screws to insure they are in place and tightened to the back lock rod.                                                                                                    | Install and / or tighten the set screws in the back lock assembly. Refer to para 4.6.                           |
|                                                                         |                                                                                                                        | Set screw(s) are loose in the back lock handle(s) prevent handles from rotating back lock rod and back lock assembly. | Check the set screws to insure they are in place and tightened to the back lock rod.                                                                                                    | Install and / or tighten the set screws in the back lock handles. Refer to para 4.6.                            |
|                                                                         | Head Board descends rapidly when back lock handles are depressed.                                                      | Lift spring(s) are broken or disconnected from the lift lever or the eye bolt(s).                                     | Check the condition of the lift spring(s).                                                                                                                                              | Reconnect or replace the lift springs. Refer to para 4.7.                                                       |
|                                                                         |                                                                                                                        | Lift spring(s) tension out of adjustment.                                                                             | Check the position of the wing nuts to insure they are on the eye bolts sufficiently.                                                                                                   | Adjust the spring tension on the lift springs. Refer to para 4.7.                                               |
|                                                                         | Head Board descends rapidly when back lock handles are depressed (continued).                                          | Lift support rod for the lift lever is disconnected.                                                                  | Check the condition of the lift support rod to insure it is in place.                                                                                                                   | Repair or replace the lift support rod. Refer to para 4.7.                                                      |
| Step assembly does not function correctly.                              | Step assembly difficult to pull out.                                                                                   | Nylon stem bumpers worn or missing. Lack of lubrication.                                                              | Check the condition of the nylon stem bumpers.                                                                                                                                          | Replace and lubricate the nylon stem bumpers. Refer to para 4.5.                                                |

## SECTION II TESTING AND TROUBLESHOOTING

| Problem                                                  | Symptom                                                                                | Probable Cause                                                                        | Check                                                                                                                                   | Correction                                                                                                              |
|----------------------------------------------------------|----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Step assembly does not function correctly.<br>-Continued | Step assembly pulls completely out of table when fully extended.                       | Step stop missing or out of alignment.                                                | Check the condition of the step stop.                                                                                                   | Repair or replace the step stop. Refer to para 4.5.                                                                     |
|                                                          | Step will not lock into position when fully extended.                                  | Lock tabs on bottom rails of step weldment are not bent down far enough.              | Check if lock tabs on bottom rails of step weldment are bent down.                                                                      | Bend the lock tabs down approximately 1/8 inch (0.32 cm) from the bottom of the step weldment rails. Refer to para 4.5. |
| Drawer(s) do not function correctly.                     | Drawer(s) difficult to slide in and out of the table.                                  | Drawer(s) not located properly in the cabinet slides.                                 | Check to insure the drawer slide is located properly in the cabinet slide.                                                              | Insert the drawer slide properly in the cabinet slide.                                                                  |
|                                                          |                                                                                        | Drawer and / or cabinet slide is damaged.                                             | Check the condition of the slides on the drawer(s) and cabinet.                                                                         | Replace the cabinet slide(s) and / or drawer assemblies.                                                                |
|                                                          |                                                                                        | Ball bearings in cabinet slides dry of lubricant or contaminated with foreign debris. | Check the ball bearings and cabinet slides.                                                                                             | Clean, lubricate or replace the cabinet slide(s).                                                                       |
| Pelvic tilt does not function correctly.                 | Pelvic tilt lift bar does not spring to "Up" position when the seat section is lifted. | Pivot points on pelvic lift bar dry of lubricant and / or dirty.                      | Check the condition of the pivot points on the pelvic lift bar.                                                                         | Clean and lubricate the pivot points on the pelvic lift bar.                                                            |
|                                                          |                                                                                        | Springs on the pelvic tilt bar are broken.                                            | Check the condition of the springs on the pelvic tilt bar.                                                                              | Replace the springs on the pelvic tilt bar.                                                                             |
|                                                          |                                                                                        | Push nuts that retain pelvic lift bar on tabs of upper weldment rubbing on bar.       | Check the position of the push nuts in relation to the pelvic lift bar.                                                                 | Repair or replace the push nuts.                                                                                        |
| Footrest assembly does not function correctly.           | Footrest does not extend or retract smoothly.                                          | The nylo tape in the footrest cabinet guides is missing or dry of lubricant.          | Check the condition of the nylo tape.                                                                                                   | Lubricate and / or replace the nylon tape in the cabinet guides. Refer to para 4.4.                                     |
|                                                          |                                                                                        | The footrest weldment is bent or damaged.                                             | Inspect the footrest weldment to insure it is straight.                                                                                 | Replace the footrest weldment. Refer to para 4.4.                                                                       |
|                                                          | Footrest pulls all the way out when fully extended.                                    | The "stop" tabs at the back of the footrest weldment are not bent down correctly.     | Inspect the footrest weldment to insure the tabs are bent down and that the rubber bumpers are in place on the footrest cabinet guides. | Repair or replace the footrest. Refer to para 4.4.                                                                      |
| Stirrups do not work correctly.                          | Stirrups do not lock into one of four lateral positions.                               | Stirrups dirty and lacking lubricant.                                                 | Inspect the stirrup assemblies for dirt and lack of lubricant.                                                                          | Clean and lubricate the stirrup assemblies.                                                                             |

## **SECTION II**

# **TESTING AND TROUBLESHOOTING**

## SECTION III SCHEDULED MAINTENANCE

### SECTION III SCHEDULED MAINTENANCE

#### 3.1 Scheduled Maintenance

Table 3-1 is a Scheduled Maintenance Chart which lists the inspections and services that should be performed

periodically on the 304 Examination Table. These inspections and services should be performed as often as indicated in the chart.

| Interval      | Inspection or Service                     | What to Do                                                                                                                                                                                                                                                                                   |
|---------------|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Semi-annually | Obvious damage                            | Visually check condition of table for obvious damage such as: cracks in components, missing components, dents in components, or any other visible damage which would cause the table to be unsafe to operate or would compromise its performance. Repair table as necessary.                 |
|               | Fasteners / hardware                      | Check table for missing or loose fasteners / hardware. Replace any missing hardware and tighten any loose hardware as necessary.                                                                                                                                                             |
|               | Warning and instructional decals          | Check for missing or illegible decals. Replace decals as necessary.                                                                                                                                                                                                                          |
|               | Pivot points / moving parts / accessories | Lubricate all exposed pivot points, moving parts, and accessories with silicone based lubricant.                                                                                                                                                                                             |
|               | Step Assembly                             | Check step assembly to insure that it slides in and out easily. Insure that the step assembly locks in place when extended. Refer to para 4.4.                                                                                                                                               |
|               | Footrest extension                        | Check that footrest extension can be easily extended and is not damaged. Refer to para 4.3.                                                                                                                                                                                                  |
|               | Stirrup assemblies                        | Check that stirrup assemblies lock into one of four different positions. Check for wear. Replace worn components as necessary. Refer to para 4.14.                                                                                                                                           |
|               | Electrical receptacle                     | Check that the electrical receptacle are functioning properly. Replace receptacle as necessary. Refer to para 4.9.                                                                                                                                                                           |
|               | Drawer Heater (Optional)                  | Where applicable, check to insure the drawer heater is heating sufficiently to warm the top drawer and that the heater ON / OFF switch indicator light illuminates when the switch is in the ON position. If necessary, replace the heater switch or heater plate. Refer to para 4.7 or 4.8. |
|               | Pelvic Tilt (Optional)                    | Check that the spring loaded pelvic tilt is operating properly. Replace springs if necessary.                                                                                                                                                                                                |
|               | Upholstery                                | Check all upholstery for rips, tears, or excessive wear. Replace cushions as necessary.                                                                                                                                                                                                      |
|               | Accessories                               | Check that all accessories have all of their components and that they function properly. If necessary, repair or replace the accessory.                                                                                                                                                      |
|               | Operational Test                          | Perform an Operational Test to determine if the table is operating within its specifications (Refer to para 2.1). Replace or adjust any malfunctioning components.                                                                                                                           |



**SECTION IV  
MAINTENANCE / SERVICE INSTRUCTIONS****4.1 Introduction****WARNING**

Refer to the Operator Manual for complete instructions on operating the examination table. Failure to do so could result in personal injury.

**NOTE**

Perform an operational test on the examination table after the repair is completed to confirm the repair was properly made and that all malfunctions were repaired.

The following paragraphs contain removal, installation, repair, and adjustment procedures for the examination table.

**4.2 Styled Upholstery Removal / Installation [Applies to models: 304 (-001 thru -004 & -011 thru -015)]****A. Removal****WARNING**

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug the table power cord from the wall outlet.
- (2) For tables without Pelvic Tilt, remove the two screws (1, Figure 4-1) that secure the seat section (A) to the upper wrap cross member (B).
- (3) Remove the two screws (2) that secure the upholstered seat section (A) to the top hinge (3).

- (4) Elevate and support the head section (C) and remove the four screws (4) that secure the upholstered head section (C) to the back plate assembly (5).

**CAUTION**

Use care when removing the upholstered top assembly as it weighs approximately 32 lbs. (14.5 kg). Failure to use proper lifting techniques or assistance could result in personal injury.


- (5) Remove the upholstered top assembly (6).
- (6) Extend the footrest and remove the upholstered footrest pad (7).

**B. Installation****CAUTION**

Use care when installing the upholstered top assembly as it weighs approximately 32 lbs. (14.5 kg). Failure to use proper lifting techniques or assistance could result in personal injury.

- (1) Lay the new upholstery assembly (6, Figure 4-1) in position on the back plate assembly (5) and upper wrap assembly (8).
- (2) Secure the head section (C) to the back plate assembly (5) with four screws (4).
- (3) Secure the seat section (A) to the top hinge (3) with two screws (2).
- (4) For tables without Pelvic Tilt, install the two screws (1) that secure the seat section (A) to the upper wrap cross member (B).
- (5) Raise and lower the head section (C) several times to insure it operates smoothly and locks in position without drifting. If necessary, refer to Testing and Troubleshooting, para 2.1.
- (6) Install the upholstered footrest pad (7).
- (7) Plug the table power cord into a wall outlet.

## SECTION IV MAINTENANCE / SERVICE



MA376600

Figure 4-1. Styled Upholstery Removal / Installation

### 4.3 Soft Touch Upholstery Removal / Installation [Applies to models: 304 (-005 thru -010)]

#### A. Removal



#### WARNING

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug the table power cord from the wall outlet.


- (2) For tables without Pelvic Tilt, remove the two screws (1, Figure 4-2) that secure the seat section (A) to the upper wrap cross member (B).
- (3) Elevate and support the head section (C) and remove the two screws (2) securing the rod support bracket (3) to the head section (C).
- (4) Lay the head section (C) forward and remove four screws (4) securing the upholstered top assembly (5) to upper wrap (6).



#### CAUTION

Use care when removing the upholstered top assembly as it weighs approximately 32 lbs. (14.5 kg). Failure to use proper lifting techniques or assistance could result in personal injury.

- (5) Remove the upholstered top assembly (5).



MA485200

**Figure 4-2. Soft Touch Upholstery Removal / Installation**

- (6) Extend the footrest shelf (7) and remove the upholstered footrest pad (8).

**B. Installation****CAUTION**

Use care when installing the upholstered top assembly as it weighs approximately 32 lbs. (14.5 kg). Failure to use proper lifting techniques or assistance could result in personal injury.

- (1) Lay the new upholstery assembly (5, Figure 4-2) in position on the upper wrap assembly (6) and secure with four screws (4).
- (2) Lay the head section (C) backward slightly and secure to rod support bracket (3) with two screws (2).
- (3) For tables without Pelvic Tilt, install the two screws (1) that secure the seat section (A) to the upper wrap cross member (B).

## SECTION IV MAINTENANCE / SERVICE

- (4) Raise and lower the head section (C) several times to insure it operates smoothly and locks in position without drifting. If necessary, refer to Testing and Troubleshooting, para 2.1.
- (5) Install the upholstered footrest pad (8) on foot rest shelf (7).
- (6) Plug the table power cord into a wall outlet

### 4.4 Footrest Extension Removal / Installation

#### A. Removal

- (1) Unplug table power cord from the wall outlet.
- (2) Pull out the on the footrest (1, Figure 4-3) until it is fully extended.

- (3) Remove the upholstered footrest pad (2) and treatment pan (3).

#### NOTE

For tables without Pelvic Tilt, remove the two screws (4) that secure the seat section (5) to the upper wrap cross member (A).

- (4) Raise the seat section (5) and using pliers or equivalent, bend up the two metal tabs (6) on the back of the footrest weldment (1) until they are horizontal.
- (5) Pull the footrest weldment (1) out of the upper wrap weldment (7).




Figure 4-3. Footrest Extension Removal / Installation

**B. Installation****NOTE**


Before installing the footrest weldment, inspect the footrest runners (B, Figure 4-3) to insure the nylon tape glides (8) are in place at the side and top of each runner. Also inspect the rubber bumpers (9), located at the back of the footrest runners to insure they are intact.

- (1) Inspect the nylon tape glides (8, Figure 4-3) and rubber bumpers (9) and replace if necessary. Place a light coating of lubricant on the glides.
- (2) Insert the footrest weldment (1) into the runners (B) of the upper wrap weldment (7) and bend the two metal tabs (6) on the footrest weldment downward until vertical.
- (3) Install the treatment pan (3) and upholstered footrest pad (2).
- (4) Plug the table power cord into wall outlet.

**4.5 Step Assembly Removal / Installation****A. Removal****WARNING**

**Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.**

- (1) Unplug the table power cord from the wall outlet.
- (2) Pull out on the step assembly (1, Figure 4-4) until it is fully extended.
- (3) While lightly pulling the step assembly outward, reach beneath it and push the step stop (2) upward until it clears the base weldment (3); then remove the step assembly from the cabinet.

**Figure 4-4. Step Assembly Removal / Installation****B. Drawer Front Replacement****NOTE**

Should it be necessary to replace the plastic step front on the step assembly, the step covering must also be replaced as it is adhered to the step front.

- (1) Remove the step covering (4, Figure 4-4) from the step assembly (5).
- (2) Reaching up through the opening at the bottom of the drawer front (6), push out on the insert panel (7) and remove it.

## SECTION IV MAINTENANCE / SERVICE

- (3) Remove the eight screws (8) that secure the drawer front (6) to the step weldment (5) and remove the drawer front.
- (4) Clean the surface of the step weldment (5), to which the step covering (4) will be attached, with alcohol or a similar cleanser to insure the adhesive back will bond to the surface of the step weldment.
- (5) Install the drawer front (6) to the step weldment (5) and secure with eight screws (8).

### NOTE

Before removing the protective cover from the adhesive backing of the step., lay the cover in place and make some light location marks to insure the step cover is installed uniformly on the step weldment.




Figure 4-5. Drawer Front Replacement

- (6) Before installing the step cover (1, Figure 4-5) lay it on the step weldment (2) and make location marks. The step cover (1) should be located so that it is positioned approximately 5/16 inch (0.794 cm) from the outer edges of the drawer front (3) and step weldment (2).

### NOTE

Using alcohol or equivalent, clean any residue off the surface of the step before installing the new step cover.

- (7) Remove the protective cover from the step cover (4, Figure 4-4) and place it in position, aligned with the location marks.
- (8) Inspect the nylon stem bumpers (9) on the step weldment (5) and replace if necessary.
- (9) Inspect the nylon stem bumpers (1, Figure 4-6) and bumper stops (2) on the runners (A) of the base weldment (3) and replace if worn.

### C. Installation




### EQUIPMENT ALERT

Before installing the step assembly into the cabinet check that the lock tabs (A, Figure 4-4) on both sides of the bottom of step weldment (5) are bent downward approximately 1/8 inch (0.318 cm) but **no farther** than the surface of nylon stem bumpers (9) next to tabs. These tabs (A) lock the step assembly in position when it is extended.

- (1) Inspect the lock tabs (A, Figure 4-4) and adjust if necessary.
- (2) Place some lubricant, such as vaseline, on the nylon stem bumpers (9).

### NOTE

When inserting step assembly into the cabinet, the step will have to be lifted slightly to clear the lock tabs at the bottom of the step assembly. It will also be necessary to push up on the step stop (2, Figure 4-4) in order for the stop to clear the base weldment.

**Figure 4-6. Nylon Bumper Replacement**

- (3) Install the step assembly (1) into the cabinet.

**CAUTION**

Extend the step assembly outward to insure it locks into place. If necessary, readjust the lock tabs (A, Figure 4-4). Failure to insure the step assembly locks into place could cause injury to the user.

- (4) Plug the table power cord into the wall outlet.

## 4.6 Back Lock Assembly Removal / Installation

### A. Removal

**WARNING**

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug table power cord from the wall outlet.
- (2) Remove the two top drawers from the side of the cabinet to gain access to the bottom of the back support rod (1, Figure 4-7).

- (3) Remove the cotter pin (2) from the back support rod (1).

**NOTE**

To prevent the back lock assembly (3) from snapping back against the upper wrap weldment (4) when the back support rod (1) is removed, slightly depress one of the back lock handles (5) while removing the back support rod (1). When the back support rod (1) is clear of the back lock assembly (3), slowly release the handle (5).

- (4) Elevate the head board assembly (6) until the back support rod (1) is clear of the upper wrap cover (7). Allow the head board (6) to rest against the seat section (8).
- (5) Remove the four screws (9) that secure the upper wrap cover (7) to the upper wrap assembly (4) and remove the upper wrap cover.
- (6) Disconnect the back lock spring (10) from the upper wrap assembly (4).
- (7) Loosen the set screw (11) and remove the back lock handle (5).
- (8) Loosen the two set screws (12) that secure the back lock rod (13) to the bracket (A) of the upper wrap assembly (4).
- (9) Pull the back lock rod (13) out of the back lock assembly (3), two washers (14) and the bracket (A) of the upper wrap assembly (4).
- (10) Remove the back lock assembly (3) and two washers (14) from the bracket (A) of the upper wrap assembly (4).


### B. Installation

- (1) Insert the back lock rod (13, Figure 4-7) thru the bracket (A) of the upper wrap assembly, two washers (14) and back lock assembly (3).

**EQUIPMENT ALERT**

Do not over-tighten the set screws in the back lock handles. Torque to 10 to 20 inch / lbs. (1.13 to 2.26 N•M).

## SECTION IV MAINTENANCE / SERVICE



MA364400

**Figure 4-7. Back Lock Assembly Removal / Installation**

- (2) Install the back lock handle (5) onto the back lock rod (13) aligning it with the other back lock handle (5) and tighten the set screw (11) to 10 to 20 inch / lbs. (1.13 to 2.26 N•M).
- (3) Connect the two back lock springs (10) to the upper wrap (4) and compress the spring hooks to secure the springs to the upper wrap assembly.



### CAUTION

Use care to prevent the head board from falling when inserting the back support rod into the back lock assembly. Failure to do may cause personal injury.

- (4) Lifting the back lock assembly (3), align the back support rod (1) with the hole in the back lock assembly and insert the rod thru the assembly.
- (5) With the head board (6) in the elevated or chair position, rotate the back lock handles (5) so the pointed end of the handles are facing toward the foot-end of the table and the handles are pointed downward approximately 15° to 20°.

**EQUIPMENT ALERT**

Use care not to over-tighten the set screws in the back lock assembly. Tighten the set screws 75 to 80 in. / lbs.(0.533 to 0.604 N•M).

- (6) Tighten one of the set screws (12) on the back lock assembly (3) to secure the back lock assembly to the back lock rod (13).
- (7) Lower the head board (6) to the horizontal position and observe the position of the back lock handles (5). The handles should be parallel with the bottom edge of the head board or pointed slightly downward.
- (8) If necessary, lift the head board, loosen the set screw on the back lock assembly and rotate the handles up or down to adjust their position. Lower the head board and check the positions.
- (9) Raise the head board (6) and tighten both set screws (12) on the back lock assembly to 75 to 80 in. / lbs. (0.533 to 0.604 N•M).
- (10) Raise and lower the head board (6) several times to insure the back support rod (1) moves up and down smoothly without binding.

**NOTE**

If the back support rod (1) binds, loosen the two set screws on the back support rod (1). Raise and lower the head board (6) several times until it operates smoothly and retighten the screws on the bracket.

- (11) Raise the head board (6) until the back support rod (1) is free from the back lock assembly (3).
- (12) Supporting the head board (6), install the cover assembly (7) and secure with four screws (9).

- (13) Rotate the back lock handles (5) to align the hole in the back lock assembly (3) and insert the back support rod (1).
- (14) Insert the cotter pin (2) in the end of the back support rod (1) and bend over the ends of the cotter pin.
- (15) Lightly lubricate the back support rod (1), check operation and install the drawers.
- (16) Plug the table power cord into wall outlet.

**4.7 Lift Lever Removal / Installation****A. Removal****WARNING**


**Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.**

- (1) Unplug the table power cord from the wall outlet.
- (2) Remove the two top drawers from the side of the cabinet to gain access to the bottom of the back support rod (1, Figure 4-8).
- (3) Remove the cotter pin (2) from the back support rod (1).

**NOTE**

To prevent the back lock assembly (3) from snapping back against the upper wrap weldment (4) when the back support rod (1) is removed, slightly depress one of the back lock handles (5) while removing the back support rod (1). When the back support rod (1) is clear of the back lock assembly (3) slowly release the handle (5).

## SECTION IV MAINTENANCE / SERVICE



MA364500

**Figure 4-8. Lift Lever Removal / Installation**

- (4) Elevate the head board assembly (6) until the back support rod (1) is clear of the upper wrap cover assembly (7). Allow the head board (6) to rest against the seat section (8).



### CAUTION

Insure the head board is positioned and secured to prevent it from falling while working on the table. Failure to do so could result in personal injury.

- (5) Remove the four screws (9) that secure the upper wrap cover (7) to the upper wrap assembly (4) and remove the upper wrap cover.
- (6) Disconnect the lift springs (10) from the lift lever (11).
- (7) Remove the push-on retaining ring (12) from one side of the lift support rod (13) and remove the rod (13) and washers (14) from the lift lever (11) and upper wrap assembly (4).

**B. Installation**

- (1) Place lift lever (11, Figure 4-8) and two flat washers (14) in position on the brackets (A) of the upper wrap assembly (4).
- (2) Insert the lift support rod (13) thru the brackets (A) on the upper wrap assembly and lift lever (11).
- (3) Insure the lift support rod (13) is centered in the bracket (A) and install the push-on retaining rings (12).
- (4) Connect the lift springs (10) to the lift lever (11).

**NOTE**


The wing nuts (1, Figure 4-9) should be threaded onto the eye bolts (2) approximately 1 inch (2.54 cm).

- (5) Check the position of the wing nuts (1, Figure 4-9) on the eye bolts (2) of the lift assembly.
- (6) Rotate the back lock handles (5, Figure 4-8) to align with the hole in the back lock assembly (3) and insert the back support rod (1).

**NOTE**

With the head board in the chair position and no weight on the table, the head board should descend 1/2 to 3/4 of the way to the horizontal position when the back lock handles are released.

- (7) Check to insure the head board (6) raises and lowers smoothly. If necessary, adjust the wing nuts (1, Figure 4-9) to adjust the tension on the eye bolts (2).
- (8) Raise the head board (6, Figure 4-8) until the back support rod (1) is free from the back lock assembly (3).
- (9) Supporting the head board (6), install the cover assembly (7) and secure with four screws (9).
- (10) Rotate the back lock handles (5) to align with the hole in the back lock assembly (3) and insert the back support rod (1).
- (11) Insert the cotter pin (2) in the end of the back support rod (1) and bend over the ends of the cotter pins.

**Figure 4-9. Lift Lever Installation**

- (12) Lightly lubricate the back support rod (1), check operation and install the drawers.
- (13) Plug table power cord into wall outlet.

**4.8 Heater ON / OFF Switch Removal / Installation****A. Removal****WARNING**

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug table power cord from wall outlet.
- (2) Using a standard screwdriver, carefully pry heater switch (1, Figure 4-10) out of upper wrap weldment (2), making sure not to scratch table.
- (3) Tag and disconnect the four wires (3) from heater switch (1).

**B. Installation**

- (1) Connect four wires (3, Figure 4-10) to heater switch (1) (Refer to para 5.1).

**NOTE**

Insure that the switch ON (I) and OFF (O) symbols are matched with proper ON or OFF designation on the decal when installing the switch.

## SECTION IV MAINTENANCE / SERVICE




**Figure 4-10. Heater ON / OFF Switch Removal / Installation**

- (2) Push heater switch (1) into upper wrap weldment (2) until heater switch snaps into place.
- (3) Plug table power cord into wall outlet.

### 4.9 Heater Plate Removal / Installation

#### A. Removal



#### WARNING

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug table power cord from wall outlet.
- (2) Remove the two drawers from foot end of table.
- (3) Remove the heater ON / OFF switch (Refer to para 4.8).
- (4) Pull footrest section (1, Figure 4-11) out as far as it will go.

#### NOTE

For tables without Pelvic Tilt, remove two screws (2) that secure the seat section (3) to the upper wrap cross member (A).

- (5) Raise up the seat section (3).

- (6) Remove the four screws (4) and stirrup guide (5) from the upper wrap weldment (6).
- (7) Remove any wrap-n-tap wire clamps (7) securing the heater plate wiring (8) to the upper wrap weldment (6).
- (8) Remove the two screws (9), heater plate (10), and heat shield (11) from bottom side of the upper wrap weldment (6).

#### B. Installation

- (1) Route the heater plate wires (8, Figure 4-11) thru the heat shield (11) then thru the wire hole (B) in the upper wrap weldment (6).



#### CAUTION


Be sure the heater plate wires are not pinched by the heater plate during installation. Failure to do so could cause personal injury.

- (2) Install the heat shield (11), and the heater plate (10) on the bottom side of the upper wrap weldment (6) and secure with two screws (9).
- (3) Install the heater ON / OFF switch (Refer to para 4.8).
- (4) Secure the heater plate wires (8) to the upper wrap weldment (6) with wrap-n-tap clamps (7).

#### NOTE

Plug table in temporarily, turn ON the heater switch and check to insure the heater plate begins to warm. Unplug the table and continue with installation procedures.

- (5) Install the stirrup guide (5) on the upper wrap weldment (6) and secure with four screws (4).
- (6) Lower the seat section (3). If necessary, for tables without Pelvic Tilt, install the two screws (2) to secure the seat section (3) to the upper cross member (A).
- (7) Push the foot rest (1) into its stowed position.
- (8) Install the two drawers in the table.
- (9) Plug table power cord into wall outlet.

**Figure 4-11. Heater Plate Removal / Installation****4.10 Stirrup Components Removal / Installation****A. Removal****WARNING**

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug table power cord from wall outlet.

**NOTE**


For tables without Pelvic Tilt, remove the two screws (1, Figure 4-12) that secure the seat section (2) to the upper wrap cross member (A).

- (2) Raise the seat section (2, Figure 4-12) up and support it.
- (3) Pull the stirrup (4) out far enough to access the stop screw (5) and remove the stop screw (5) from the stirrup (4).
- (4) Pull the stirrup (4) out of the pivot boss (6).
- (5) Remove the pivot boss (6) and stirrup guide bracket (7) from the upper wrap weldment (8).
- (6) If worn, remove the stirrup index spring (9) from the stirrup guide bracket (7).

**B. Installation**

- (1) If removed, install the stirrup index spring (9, Figure 4-12) on the guide bracket (7).

## SECTION IV MAINTENANCE / SERVICE



MA371100

**Figure 4-12. Stirrup Components Removal / Installation**

- (2) Install the guide bracket (7) in the upper wrap weldment (8) and secure with the pivot boss (6).
- (3) Slide the stirrup (4) thru the slots (B) in the pivot boss (6) and the guide bracket (7).
- (4) Install the stop screw (5) on the stirrup (4).
- (5) Push the footrest section (3) all the way into its stowed position.
- (6) Lower the seat section (2). If necessary, for tables without Pelvic Tilt, install two screws to secure the seat section (2) to the upper wrap assembly (8).
- (7) Plug the table power cord into wall outlet.
- (8) Check the stirrups to insure they work smoothly and lock into the various positions.

**4.11 Electrical Receptacle Removal / Installation (120 VAC Units)****A. Removal****WARNING**

**Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.**

- (1) Unplug table power cord from wall outlet.
- (2) Extend the stirrups (1, Figure 4-13) and footrest (2) out to full extension.
- (3) Remove the screw (3) from the front of the receptacle cover (4).

**NOTE**

For tables without Pelvic Tilt, remove the two screws (5) that secure the seat section (6) to the upper wrap cross member (A).

- (4) Raise up the seat section (6).
- (5) Remove the screw (7) from inside the upper wrap assembly (8) and remove the receptacle cover (4) from the upper wrap assembly.
- (6) Remove the two screws (9) that secure the receptacle (10) to the upper wrap assembly (8).
- (7) Pull the receptacle (10) out of the upper wrap assembly (8).

**NOTE**

Before removing the electrical leads and ground wire from the receptacle, tag each wire for installation onto the replacement receptacle. If the table has a drawer heater there will be five leads and without the drawer heater there are three.

- (8) Tag and disconnect the electrical leads and ground wire (11) from the receptacle (10) and remove the receptacle.

**B. Installation****CAUTION**

When connecting the electrical leads and ground wire (11, Figure 4-13) to the receptacle (10) be sure the insulation on the leads covers sufficiently to prevent electrical shorts to the cabinet. The black leads connect to the side of the receptacle with the black screws and the white leads connect to the side with the silver screws. Insure the ground (green) lead is connected to the ground terminal on the receptacle and to the table. Failure to do so could result in personal injury.


- (1) Connect electrical leads and ground wire (11) to the appropriate terminals on the receptacle (10) (Refer to para 5.1).

**CAUTION**

Be sure the receptacle is positioned in the cavity of the upper wrap assembly so that none of the electrical terminals or exposed wires are contacting the upper wrap assembly.

- (2) Insert the receptacle (10) into its cavity in the upper wrap assembly (8) and secure with two screws (9).
- (3) Place the receptacle cover (4) on the receptacle (10) and secure to upper wrap (8) with screw (3) and screw (7).
- (4) Push the footrest (2) and stirrups (1) into their stowed positions.
- (5) Lower the seat section (6). If necessary, for tables without Pelvic Tilt, install two screws (5) to secure the seat section (6) to the upper wrap cross member (A).
- (6) Plug the table power cord into wall outlet and check that there is power to the receptacle.

## SECTION IV MAINTENANCE / SERVICE



MA364700

**Figure 4-13. Electrical Receptacle Removal / Installation  
120 VAC Units**

### 4.12 Typical Electrical Receptacle Removal / Installation (220 VAC Units)

#### A. Removal



#### **WARNING**

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug table power cord from wall outlet.
- (2) Extend the stirrups (1, Figure 4-14) out to full extension.

- (3) Extend the foot rest (2) out to full extension.

#### **NOTE**

For tables without Pelvic Tilt, remove the two screws (3) that secure the seat section (4) to the upper wrap cross member (A).

- (4) Raise the seat section (4) up.
- (5) Remove two screws (5) from inside the upper wrap (6) and partially separate the receptacle cover (7) from the upper wrap (6).

#### **NOTE**

Before removing the electrical leads and ground wire from the receptacle, tag each wire for installation onto the replacement receptacle. If the table has a drawer heater there will be five leads and without the drawer heater there will be three.

## SECTION IV MAINTENANCE / SERVICE

- (6) Tag and disconnect electrical leads and ground wire (8) from receptacle (9).

### NOTE

The position, as well as the number of tabs (A, Figure 4-15) on the receptacle will vary depending upon the country the receptacle was designed for (UK shown).

- (7) Remove receptacle (1, Figure 4-15) by using a small flat-bladed screwdriver to pry the switch bezel (2) upward while pressing gently on the back of the receptacle to allow the tabs (A) to “pop” out of the switch bezel.


### B. Installation



### CAUTION

When connecting electrical leads and ground wire (8, Figure 4-14) to the receptacle (9) be sure the insulation on the leads covers sufficiently to prevent electrical shorts to the cabinet.

- (1) Pull electrical leads and ground wire (8) thru receptacle cover (7) and switch bezel (10) and connect to proper terminals of receptacle (9) (Refer to para 5.1).
- (2) Insert receptacle (9) thru switch bezel (10) and receptacle cover (7), pushing gently until receptacle locks into place.
- (3) Align receptacle cover (7) with holes in upper wrap (6) and secure with two screws (5).



MA485800

**Figure 4-14. Typical Electrical Receptacle Removal / Installation  
220 VAC Units (UK shown)**

## SECTION IV MAINTENANCE / SERVICE




**Figure 4-15. 220 VAC Electrical Receptacle Removal / Installation (UK shown)**

- (4) Lower the seat section (4).

### NOTE

For tables without Pelvic Tilt, install the two screws (3) that secure the seat section (4) to the upper wrap cross member (A).

- (5) Push the footrest (2) and stirrups (1) into their stowed positions.
- (6) Plug the table power cord into wall outlet and check that there is power to the receptacle.

### 4.13 Fuse Removal / Installation (220 VAC Units Only)

#### A. Removal



### WARNING

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug table power cord (1, Figure 4-16) from AC inlet (2).
- (2) Using a small flat-bladed screwdriver, press inward on two locking tabs (A) and pull fuse drawer (3) from AC inlet (2).
- (3) Pull two fuses (4) out of fuse drawer (3).

#### B. Installation

- (1) Insert two fuses (4) into fuse drawer (3).
- (2) Insert fuse drawer (3) into AC inlet (2) and push until fuse drawer locks into place.
- (3) Plug table power cord (1) into AC inlet (2).

## SECTION IV MAINTENANCE / SERVICE




Figure 4-16. Fuse Removal / Installation

### 4.14 AC Inlet Removal / Installation (220 VAC Units)

#### A. Removal



#### WARNING

Always disconnect electrical power to the unit before removing any of the unit's covers/shrouds or making any repairs to prevent the possibility of electrical shock. Failure to comply with these instructions could result in severe personal injury or death.

- (1) Unplug table power cord (1, Figure 4-17) from AC inlet (2).
- (2) Remove three side drawers to gain access to AC inlet cover (3).
- (3) Remove two screws (4) and partially separate AC inlet cover (3) from base assembly (5).




Figure 4-17. AC Inlet Removal / Installation

## **SECTION IV MAINTENANCE / SERVICE**

- (4) Tag and disconnect electrical leads (6) from terminals of AC inlet (2).
- (5) Remove AC inlet (2) from base assembly (5) by simultaneously depressing two tabs (A) (one tab on each side of AC inlet) and pushing outward.

### **B. Installation**

- (1) Insert AC inlet (2) thru hole in base assembly (5) and push inward until AC inlet locks into place.
- (2) Connect electrical leads (6) to proper terminals of AC inlet (2) (Refer to para 5.1).
- (3) Align AC inlet cover (3) with holes in base assembly (5) and secure with two screws (4).
- (4) Install three side drawers.
- (5) Plug table power cord (1) into AC inlet (2) and check that there is power to the receptacle.


## SECTION V SCHEMATICS AND DIAGRAMS

### 5.1 Electrical Schematics / Wiring Diagrams


connections between the electrical components in the 120 VAC table, as Figure 5-2 does for the 220 VAC table.

Figure 5-1 illustrates the logic / current flow and wiring


#### UNIT WITHOUT HEATER



#### UNIT WITH HEATER (OFF)



#### UNIT WITH HEATER (ON)




MA357200


**Figure 5-1. Electrical Schematic / Wiring Diagram  
304(-001 thru -004 & -007 thru -014) 120 VAC Units**

# SECTION V SCHEMATICS AND DIAGRAMS

## UNIT WITHOUT HEATER



## UNIT WITH HEATER (OFF)



## UNIT WITH HEATER (ON)






**Figure 5-2. Electrical Schematic / Wiring Diagram 304(-005, -006, -015, -016) 220 VAC Units  
Used on Units with Serial Numbers GL1000 thru GL1154 & LC1000 thru LC2092**

# SECTION V SCHEMATICS AND DIAGRAMS

## UNIT WITHOUT HEATER



## UNIT WITH HEATER (OFF)



## UNIT WITH HEATER (ON)




**Figure 5-2. Electrical Schematic / Wiring Diagram 304(-005, -006, -015, -016) 220 VAC Units  
Used on Units with Serial Numbers GL1155 & LC2093 thru Present**

## **SECTION V**

# **SCHEMATICS AND DIAGRAMS**

## **SECTION VI PARTS LIST**

### **6.1 Introduction**

The illustrated parts list provides information for identifying and ordering the parts necessary to maintain the unit in peak operating condition. Refer to paragraph 1.5 for parts ordering information.

### **6.2 Description of Columns**

The Item column of the parts list gives a component its own unique number. The same number is given to the component in the parts illustration. This allows a part number of a component to be found if the technician can visually spot the part on the illustration. The technician simply finds the component in question on the illustration and notes the item number of that component. Then, he finds that item number in the parts list. The row corresponding to the item number gives the technician the part number, a description of the component, and quantity of parts per subassembly. Also, if a part number is known, the location of that component can be determined by looking for the item number of the component on the illustration.

The Part No. column lists the MIDMARK part number for that component.

The Description column provides a physical description of the component.

The Qty. column lists the number of units of a particular component that is required for the subassembly. The letters "AR" denote "as required" when quantities of a particular component cannot be determined, such as: adhesive.

Bullets { • } in the Part No. column and the Description column show the indenture level of a component. If a component does not have a bullet, it is a main component of that illustration. If a component has a bullet, it is a subcomponent of the next component listed higher in the parts list than itself that does not have a bullet. Likewise, if a component has two bullets, it is a subcomponent of the next component listed higher in the parts list than itself that has only one bullet.


### **6.3 Torque Specifications and Important Assembly Notes**

When specific assembly torque specifications, measurements, or procedures have been identified, by our engineering department, as required to assure proper function of the unit, those torque specifications measurements, and procedures will be noted on the parts illustrations. Adherence to these requirements is essential.

# Pictorial Index

## SECTION VI PARTS LIST

| UPHOLSTERY COLOR<br>CODES<br>[replace -xxx] |                 |
|---------------------------------------------|-----------------|
| -200 .....                                  | Sand Grey       |
| -201 .....                                  | Slate Grey      |
| -202 .....                                  | Iris Blue       |
| -203 .....                                  | Nile Green      |
| -204 .....                                  | Terra Rosa      |
| -205 .....                                  | Royal Lavendar  |
| -206 .....                                  | Wedgewood       |
| -207 .....                                  | Monaco          |
| -208 .....                                  | Royal Carriage  |
| -209 .....                                  | Monet           |
| -210 .....                                  | Soft Pearl      |
| -211 .....                                  | Waterford       |
| -212 .....                                  | English Gardens |
| -213 .....                                  | Cabernet        |
| -214 .....                                  | Tapestry        |
| -215 .....                                  | Cathedral       |
| -999 .....                                  | Special         |




### Used on units with Serial Number GJ1000 and GK1000 thru Present

| Item                                                                                                                          | Part No. | Description                                                                                                    | Page | Item                                                                                          | Part No. | Description                         | Page  |
|-------------------------------------------------------------------------------------------------------------------------------|----------|----------------------------------------------------------------------------------------------------------------|------|-----------------------------------------------------------------------------------------------|----------|-------------------------------------|-------|
| <p><b>Note:</b> The -xxx in the model number denotes upholstery color.<br/> <b>Refer to color code chart on this page</b></p> |          |                                                                                                                |      | 1                                                                                             | •        | • Table Top Components .....        | 6-3   |
| 304-001-xxx                                                                                                                   |          | 304 Exam Table - R.H. (110 V.) with Vacu-Form Upholstery {serial # prefix [GJ]} .....                          | 6-2  | 2                                                                                             | •        | • Upper Wrap Components.....        | 6-5   |
| 304-002-xxx                                                                                                                   |          | 304 Exam Table - L.H. (110 V.) with Vacu-Form Upholstery {serial # prefix [GJ]} .....                          | 6-2  | 3                                                                                             | •        | • Stirrup Components .....          | 6-6   |
| 304-003-xxx                                                                                                                   |          | 304 Exam Table - R.H. (110 V.) with Vacu-Form Upholstery (w/ Heater & Pelvic Lift) {serial # prefix [GK]} .... | 6-2  | 4                                                                                             | •        | • Cabinet Components .....          | 6-7   |
| 304-004-xxx                                                                                                                   |          | 304 Exam Table - L.H. (110 V.) with Vacu-Form Upholstery (w/ Heater & Pelvic Lift) {serial # prefix [GK]} .... | 6-2  | 5                                                                                             | •        | • Step Assembly .....               | 6-9   |
|                                                                                                                               |          |                                                                                                                |      | 6                                                                                             | •        | • Electrical Components .....       | 6-10  |
|                                                                                                                               |          |                                                                                                                |      | <p><b>Available Accessories</b><br/> <b>Refer to MEDICAL ACCESSORY BOOK {004-0096-00}</b></p> |          |                                     |       |
|                                                                                                                               |          |                                                                                                                |      | 9A01010                                                                                       |          | Knee Crutch Set .....               | 9A01  |
|                                                                                                                               |          |                                                                                                                |      | 9A0200*                                                                                       |          | Armboard Assembly .....             | 9A02  |
|                                                                                                                               |          |                                                                                                                |      | 9A04001                                                                                       |          | Procto Rest Assembly .....          | 9A04  |
|                                                                                                                               |          |                                                                                                                |      | 9A70000                                                                                       |          | Stainless Steel Treatment Pan ..... | 6-5   |
|                                                                                                                               |          |                                                                                                                |      | 9A104001                                                                                      |          | Urology Drain Pan .....             | 9A104 |
|                                                                                                                               |          |                                                                                                                |      | 9A180002                                                                                      |          | Welch Allyn Bracket .....           | 9A180 |
|                                                                                                                               |          |                                                                                                                |      | 9A20600*                                                                                      |          | Knee Crutch Set .....               | 9A206 |
|                                                                                                                               |          |                                                                                                                |      | 9A21000*                                                                                      |          | Sideboard Assembly .....            | 9A210 |
|                                                                                                                               |          |                                                                                                                |      | 9A28100*                                                                                      |          | Welch Allyn Bracket .....           | 9A281 |

**Always Specify Model & Serial Number**

# Pictorial Index

## SECTION VI PARTS LIST



### UPHOLSTERY COLOR CODES [replace -xxx]

|      |                 |
|------|-----------------|
| -200 | Sand Grey       |
| -201 | Slate Grey      |
| -202 | Iris Blue       |
| -203 | Nile Green      |
| -204 | Terra Rosa      |
| -205 | Royal Lavendar  |
| -206 | Wedgewood       |
| -207 | Monaco          |
| -208 | Royal Carriage  |
| -209 | Monet           |
| -210 | Soft Pearl      |
| -211 | Waterford       |
| -212 | English Gardens |
| -213 | Cabernet        |
| -214 | Tapestry        |
| -215 | Cathedral       |
| -999 | Special         |

MA354000

### Used on units with Serial Number GL1000 thru Present


| Item | Part No.    | Description                                                                                                          | Page  | Item     | Part No. | Description                                          | Page  |
|------|-------------|----------------------------------------------------------------------------------------------------------------------|-------|----------|----------|------------------------------------------------------|-------|
|      |             | <b>Note:</b> The -xxx in the model number denotes upholstery color.<br><b>Refer to color code chart on this page</b> |       | 5        | •        | • Step Assembly .....                                | 6-9   |
|      | 304-005-xxx | 304 Exam Table - R.H. Export (220 V.) with SoftTouch Upholstery {serial # prefix [GL]} .....                         | 6-2.1 | 6        | •        | • Electrical Components .....                        | 6-11  |
|      | 304-006-xxx | 304 Exam Table - L.H. Export (220 V.) with SoftTouch Upholstery {serial # prefix [GL]} .....                         | 6-2.1 |          |          | <b>Available Accessories</b>                         |       |
| 1    | •           | • Table Top Components .....                                                                                         | 6-4   |          |          | <b>Refer to MEDICAL ACCESSORY BOOK {004-0096-00}</b> |       |
| 2    | •           | • Upper Wrap Components .....                                                                                        | 6-5   | 9A01010  |          | Knee Crutch Set .....                                | 9A01  |
| 3    | •           | • Stirrup Components .....                                                                                           | 6-6   | 9A0200*  |          | Armboard Assembly .....                              | 9A02  |
| 4    | •           | • Cabinet Components .....                                                                                           | 6-8   | 9A04001  |          | Procto Rest Assembly .....                           | 9A04  |
|      |             |                                                                                                                      |       | 9A70000  |          | Stainless Steel Treatment Pan .....                  | 6-5   |
|      |             |                                                                                                                      |       | 9A104001 |          | Urology Drain Pan .....                              | 9A104 |
|      |             |                                                                                                                      |       | 9A105002 |          | Pelvic Lift Accessory .....                          | 9A105 |
|      |             |                                                                                                                      |       | 9A180002 |          | Welch Allyn Bracket .....                            | 9A180 |
|      |             |                                                                                                                      |       | 9A20600* |          | Knee Crutch Set .....                                | 9A206 |
|      |             |                                                                                                                      |       | 9A21000* |          | Sideboard Assembly .....                             | 9A210 |
|      |             |                                                                                                                      |       | 9A246002 |          | Heater Assembly .....                                | 9A246 |
|      |             |                                                                                                                      |       | 9A28100* |          | Welch Allyn Bracket .....                            | 9A281 |

Always Specify Model &amp; Serial Number

# Pictorial Index

## SECTION VI PARTS LIST

| UPHOLSTERY COLOR<br>CODES<br><i>[replace -xxx]</i> |                 |
|----------------------------------------------------|-----------------|
| -200 .....                                         | Sand Grey       |
| -201 .....                                         | Slate Grey      |
| -202 .....                                         | Iris Blue       |
| -203 .....                                         | Nile Green      |
| -204 .....                                         | Terra Rosa      |
| -205 .....                                         | Royal Lavendar  |
| -206 .....                                         | Wedgewood       |
| -207 .....                                         | Monaco          |
| -208 .....                                         | Royal Carriage  |
| -209 .....                                         | Monet           |
| -210 .....                                         | Soft Pearl      |
| -211 .....                                         | Waterford       |
| -212 .....                                         | English Gardens |
| -213 .....                                         | Cabernet        |
| -214 .....                                         | Tapestry        |
| -215 .....                                         | Cathedral       |
| -999 .....                                         | Special         |




### Used on units with Serial Number JE1000, JF1000, JG1000 and JH1000 thru Present

| Item                                                                                                                          | Part No. | Description                                                                                                           | Page  | Item                                                                                          | Part No. | Description                         | Page  |
|-------------------------------------------------------------------------------------------------------------------------------|----------|-----------------------------------------------------------------------------------------------------------------------|-------|-----------------------------------------------------------------------------------------------|----------|-------------------------------------|-------|
| <p><b>Note:</b> The -xxx in the model number denotes upholstery color.<br/> <b>Refer to color code chart on this page</b></p> |          |                                                                                                                       |       | 1                                                                                             | •        | • Table Top Components .....        | 6-4   |
| 304-007-xxx                                                                                                                   |          | 304 Exam Table - R.H. (110 V.)<br>with Soft Touch Upholstery<br>{serial # prefix [JE]} .....                          | 6-2.2 | 2                                                                                             | •        | • Upper Wrap Components .....       | 6-5   |
| 304-008-xxx                                                                                                                   |          | 304 Exam Table - L.H. (110 V.)<br>with Soft Touch Upholstery<br>{serial # prefix [JF]} .....                          | 6-2.2 | 3                                                                                             | •        | • Stirrup Components .....          | 6-6   |
| 304-009-xxx                                                                                                                   |          | 304 Exam Table - R.H. (110 V.)<br>with Soft Touch Upholstery (w/ Heater<br>& Pelvic Lift) {serial # prefix [JG]} .... | 6-2.2 | 4                                                                                             | •        | • Cabinet Components .....          | 6-7   |
| 304-0010-xxx                                                                                                                  |          | 304 Exam Table - L.H. (110 V.)<br>with Soft Touch Upholstery (w/ Heater<br>& Pelvic Lift) {serial # prefix [JH]} .... | 6-2.2 | 5                                                                                             | •        | • Step Assembly .....               | 6-9   |
|                                                                                                                               |          |                                                                                                                       |       | 6                                                                                             | •        | • Electrical Components .....       | 6-10  |
|                                                                                                                               |          |                                                                                                                       |       | <p><b>Available Accessories</b><br/> <b>Refer to MEDICAL ACCESSORY BOOK {004-0096-00}</b></p> |          |                                     |       |
|                                                                                                                               |          |                                                                                                                       |       | 7                                                                                             | 9A01010  | Knee Crutch Set .....               | 9A01  |
|                                                                                                                               |          |                                                                                                                       |       | 8                                                                                             | 9A0200*  | Armboard Assembly .....             | 9A02  |
|                                                                                                                               |          |                                                                                                                       |       | 9                                                                                             | 9A04001  | Procto Rest Assembly .....          | 9A04  |
|                                                                                                                               |          |                                                                                                                       |       | 10                                                                                            | 9A70000  | Stainless Steel Treatment Pan ..... | 6-5   |
|                                                                                                                               |          |                                                                                                                       |       | 11                                                                                            | 9A104001 | Urology Drain Pan .....             | 9A104 |
|                                                                                                                               |          |                                                                                                                       |       | 12                                                                                            | 9A105002 | Pelvic Lift Assembly .....          | 9A105 |
|                                                                                                                               |          |                                                                                                                       |       | 13                                                                                            | 9A180002 | Welch Allyn Bracket .....           | 9A180 |
|                                                                                                                               |          |                                                                                                                       |       | 14                                                                                            | 9A20600* | Knee Crutch Set .....               | 9A206 |
|                                                                                                                               |          |                                                                                                                       |       | 15                                                                                            | 9A21000* | Sideboard Assembly .....            | 9A210 |
|                                                                                                                               |          |                                                                                                                       |       | 16                                                                                            | 9A28100* | Welch Allyn Bracket .....           | 9A281 |

**Always Specify Model & Serial Number**

| UPHOLSTERY COLOR<br>CODES<br><i>[replace -xxx]</i> |                 |
|----------------------------------------------------|-----------------|
| -200 .....                                         | Sand Grey       |
| -201 .....                                         | Slate Grey      |
| -202 .....                                         | Iris Blue       |
| -203 .....                                         | Nile Green      |
| -204 .....                                         | Terra Rosa      |
| -205 .....                                         | Royal Lavendar  |
| -206 .....                                         | Wedgewood       |
| -207 .....                                         | Monaco          |
| -208 .....                                         | Royal Carriage  |
| -209 .....                                         | Monet           |
| -210 .....                                         | Soft Pearl      |
| -211 .....                                         | Waterford       |
| -212 .....                                         | English Gardens |
| -213 .....                                         | Cabernet        |
| -214 .....                                         | Tapestry        |
| -215 .....                                         | Cathedral       |
| -999 .....                                         | Special         |



MA354000


### Used on units with Serial Number LC1000 thru Present

| Item | Part No.    | Description                                                                                                          | Page  | Part No.                                                                             | Description.....                    | Page  |
|------|-------------|----------------------------------------------------------------------------------------------------------------------|-------|--------------------------------------------------------------------------------------|-------------------------------------|-------|
|      |             | <b>Note:</b> The -xxx in the model number denotes upholstery color.<br><b>Refer to color code chart on this page</b> |       | 4                                                                                    | • Cabinet Components .....          | 6-8   |
|      |             |                                                                                                                      |       | 5                                                                                    | • Step Assembly .....               | 6-9   |
|      |             |                                                                                                                      |       | 6                                                                                    | • Electrical Components.....        | 6-11  |
|      | 304-015-xxx | 304 Exam Table - R.H. Export (220 V.) with Vacu-Form Upholstery {serial # prefix [LC]} .....                         | 6-2.3 | <b>Available Accessories</b><br><b>Refer to MEDICAL ACCESSORY BOOK {004-0096-00}</b> |                                     |       |
|      | 304-016-xxx | 304 Exam Table - L.H. Export (220 V.) with Vacu-Form Upholstery {serial # prefix [LC]} .....                         | 6-2.3 | 9A01010                                                                              | Knee Crutch Set .....               | 9A01  |
| 1    | •           | • Table Top Components .....                                                                                         | 6-3   | 9A0200*                                                                              | Armboard Assembly .....             | 9A02  |
| 2    | •           | • Upper Wrap Components .....                                                                                        | 6-5   | 9A04001                                                                              | Procto Rest Assembly .....          | 9A04  |
| 3    | •           | • Stirrup Components.....                                                                                            | 6-6   | 9A70000                                                                              | Stainless Steel Treatment Pan ..... | 6-5   |
|      |             |                                                                                                                      |       | 9A104001                                                                             | Urology Drain Pan .....             | 9A104 |
|      |             |                                                                                                                      |       | 9A105002                                                                             | Pelvic Lift Accessory .....         | 9A105 |
|      |             |                                                                                                                      |       | 9A180002                                                                             | Welch Allyn Bracket .....           | 9A180 |
|      |             |                                                                                                                      |       | 9A20600*                                                                             | Knee Crutch Set .....               | 9A206 |
|      |             |                                                                                                                      |       | 9A21000*                                                                             | Sideboard Assembly .....            | 9A210 |
|      |             |                                                                                                                      |       | 9A28100*                                                                             | Welch Allyn Bracket .....           | 9A281 |

Always Specify Model & Serial Number


# Table Top Components (Vacu-Form)

## SECTION VI PARTS LIST




### NOTE

Vacu-Form Uph. Kit (002-0570-00) is no longer available. Replace this number with **002-0726-00 (specify color)**.



If table has knee crutches, measure mounting block before ordering uph. top.



If mounting block is less than 3.6 in. (9.2 cm) long, you must also order the Extended Knee Crutch Bracket Kit (002-0517-00).

MA618700

MA351203i

### Used on Units with Serial Numbers GJ1000 thru GJ7229, GK1000 thru GK10609, & LC1000 thru LC2295

| Item | Part No.      | Description                                                             | Qty | Item | Part No.      | Description                                              | Qty |
|------|---------------|-------------------------------------------------------------------------|-----|------|---------------|----------------------------------------------------------|-----|
| 1    | 002-0570-00   | Vacu-Form Upholstery Kit - <b>See NOTE</b><br>(includes items 2 thru 5) |     | 15   | 042-0170-40   | Winghead Screw .....                                     | 4   |
| 2    | • n/a         | • Upholstered Top .....                                                 | 1   | 16   | 040-0010-01   | Screw .....                                              | 9   |
| 3    | • 016-0022-00 | • Stud .....                                                            | 4   | 17   | 029-0151-03   | Back Support Rod Assembly<br>(includes 18 thru 20) ..... | 1   |
| 4    | • 053-0950-00 | • Scuff Plate .....                                                     | 1   | 18   | • 057-0013-00 | • Back Support Rod1 .....                                | 1   |
| 5    | • 042-0040-00 | • Staple .....                                                          | 10  | 19   | • 042-0001-01 | • Roll Pin .....                                         | 1   |
| 6    | 028-0439-00   | Upholstered Footrest ( <b>specify color</b> ) .....                     | 1   | 20   | • 050-0556-40 | • Back Support Bracket .....                             | 1   |
| 7    | 053-0424-00   | Footrest glide .....                                                    | 4   | 21   | 040-0006-26   | Screw .....                                              | 2   |
| 8    | 029-0017-00   | Paper Tear Strip .....                                                  | 2   | 22   | 050-0194-00   | Plate .....                                              | 1   |
| 9    | 016-0715-41   | Hinge .....                                                             | 1   | 23   | 040-0010-35   | Screw .....                                              | 4   |
| 10   | 029-1968-00   | Back Board Assembly .....                                               | 1   | 24   |               | Upper Wrap (Refer to "Upper Wrap<br>Assembly") .....     | Ref |
| 11   | 041-0013-00   | T Nut (Used on L.H. Units Only) .....                                   | 2   | 25   | 040-0010-01   | Thumb Screw .....                                        | 2   |
| 12   | 055-0005-04   | Dowel .....                                                             | 1   | 26   | 053-0852-00   | Paper Roll Holder .....                                  | 1   |
| 13   | 053-0024-00   | Recess Bumper .....                                                     | 2   |      |               |                                                          |     |
| 14   | 040-0008-95   | Screw .....                                                             | 2   |      |               |                                                          |     |

Always Specify Model & Serial Number

# Table Top Components (Vacu-Form)

## SECTION VI PARTS LIST

| UPHOLSTERY COLOR<br>CODES<br>[replace -xxx] |                 |
|---------------------------------------------|-----------------|
| -200 .....                                  | Sand Grey       |
| -201 .....                                  | Slate Grey      |
| -202 .....                                  | Iris Blue       |
| -203 .....                                  | Nile Green      |
| -204 .....                                  | Terra Rosa      |
| -205 .....                                  | Royal Lavendar  |
| -206 .....                                  | Wedgewood       |
| -207 .....                                  | Monaco          |
| -208 .....                                  | Royal Carriage  |
| -209 .....                                  | Monet           |
| -210 .....                                  | Soft Pearl      |
| -211 .....                                  | Waterford       |
| -212 .....                                  | English Gardens |
| -213 .....                                  | Cabernet        |
| -214 .....                                  | Tapestry        |
| -215 .....                                  | Cathedral       |
| -999 .....                                  | Special         |

**NOTE**


2.6 in.  
(6.6 cm)

3.6 in.  
(9.2 cm)

If table has knee crutches, measure mounting block before ordering uph. top.

If mounting block is less than 3.6 in. (9.2 cm) long, you must also order the Extended Knee Crutch Bracket Kit (002-0517-00).

MA618700



MA483805i


### Used on Units with Serial Numbers GJ7230, GK10610, & LC2296 thru present

| Item | Part No.       | Description                                                                                | Qty | Item | Part No.      | Description                                                    | Qty |
|------|----------------|--------------------------------------------------------------------------------------------|-----|------|---------------|----------------------------------------------------------------|-----|
| 1    | 002-0740-xxx   | Vacu-Form Upholstery Top<br>(includes items 2 thru 7)<br>(replace -xxx w/color code) ..... | 1   | 13   | 053-0424-00   | Footrest Glide .....                                           | 2   |
| 2    | • 053-1319-01  | • Paper Roll Holder .....                                                                  | 1   | 14   | 029-0017-00   | Paper Tear Strap .....                                         | 2   |
| 3    | • 040-0008-46  | • Screw .....                                                                              | 4   | 15   | 053-0014-00   | Bumper .....                                                   | 2   |
| 4    | • 016-0922-00  | • Hinge .....                                                                              | 1   | 16   | 040-0010-01   | Screw .....                                                    | 7   |
| 5    | • 040-0250-03  | • Screw .....                                                                              | 7   | 17   | 029-0151-03   | Back Support Rod Assembly<br>(includes items 18 thru 20) ..... | 1   |
| 6    | • 053-1290-00  | • Recess Bumper .....                                                                      | 2   | 18   | • 042-0001-01 | • Roll Pin .....                                               | 1   |
| 7    | • 040-0008-104 | • Screw .....                                                                              | 2   | 19   | • 057-0013-00 | • Back Support Rod .....                                       | 1   |
| 8    | 055-0005-08    | Dowel .....                                                                                | 1   | 20   | • 050-0556-40 | • Back Support Bracket .....                                   | 1   |
| 9    | 053-0950-00    | Scuff Plate .....                                                                          | 1   | 21   | 040-0006-26   | Screw .....                                                    | 2   |
| 10   | 042-0040-00    | Staple .....                                                                               | AR  | 22   | 050-0194-00   | Plate .....                                                    | 1   |
| 11   | 016-0022-00    | Stud .....                                                                                 | 4   | 23   | 040-0010-35   | Screw .....                                                    | 4   |
| 12   | 028-0439-00    | Upholstered Footrest (specify color) .....                                                 | 1   | 24   |               | Refer to "Upper Wrap Assembly" .....                           | Ref |

Always Specify Model &amp; Serial Number

# Table Top Components (Soft Touch)

## SECTION VI PARTS LIST




| Item | Part No.      | Description                                                            | Quantity | Item | Part No.      | Description                                                 | Quantity |
|------|---------------|------------------------------------------------------------------------|----------|------|---------------|-------------------------------------------------------------|----------|
| 1    | 002-0598-00   | Soft Touch Upholstery (Includes Items 2 thru 14 [Specify Color]) ..... | 1        | 15   | 028-0439-00   | Upholstered Footrest (Specify Color).....                   | 1        |
| 2    | • 053-0043-04 | • R.H. Pole Socket .....                                               | 1        | 16   | 055-0005-00   | Dowel .....                                                 | 1        |
| 3    | • 040-0006-26 | • Screw .....                                                          | 4        | 17   | 029-0017-00   | Paper Tear Strip .....                                      | 2        |
| 4    | • 042-0605-00 | • Wire Nail .....                                                      | 2        | 18   | 029-0151-03   | Back Support Rod Assembly (Includes 19 thru 21).....        | 1        |
| 5    | • 053-0043-03 | • L.H. Pole Socket.....                                                | 1        | 19   | • 057-0013-00 | • Back Support Rod .....                                    | 1        |
| 6    | • 053-0024-00 | • Recess Bumper .....                                                  | 2        | 20   | • 042-0001-01 | • Roll Pin .....                                            | 1        |
| 7    | • 040-0008-95 | • Screw .....                                                          | 2        | 21   | • 050-0556-40 | • Back Support Bracket.....                                 | 1        |
| 8    | • 050-0194-00 | • Plate .....                                                          | 4        | 22   | 040-0010-35   | Screw .....                                                 | 4        |
| 9    | • 040-0006-26 | • Screw .....                                                          | 4        | 23   | 040-0010-01   | Screw .....                                                 | 2        |
| 10   | • 053-0950-00 | • Scuff Plate (Used w/ Pelvic Lift Only) ..                            | 1        | 24   |               | Upper Wrap (Refer to "Upper Wrap Assembly" Elsewhere) ..... | Ref      |
| 11   | • 042-0040-00 | • Staple (Used w/ Pelvic Lift Only) .....                              | 10       | 25   | 040-0010-01   | Screw (Non Pelvic Lift Units Only) .....                    | 2        |
| 12   | • 016-0715-41 | • Hinge .....                                                          | 1        |      |               |                                                             |          |
| 13   | • 053-0424-00 | • Footrest glide.....                                                  | 4        |      |               |                                                             |          |
| 14   | • 040-0010-01 | • Screw .....                                                          | 7        |      |               |                                                             |          |

Always Specify Model & Serial Number

# Upper Wrap Components

## SECTION VI PARTS LIST



MA354101


Used on Units with Serial Numbers GJ1000 thru GJ4377, GK1000 thru GK6755, JE1000 thru JE1348, JF1000 thru JF1094, JG1000 thru JG2278, JH1000 thru JH1217 & LC1000 thru LC1694

| Item | Part No.     | Description                                  | Qty | Item | Part No.    | Description                                                            | Qty |
|------|--------------|----------------------------------------------|-----|------|-------------|------------------------------------------------------------------------|-----|
| 1    | 042-0159-00  | Retaining Ring.....                          | 2   | 24   | 025-0008-00 | Back Lock Spring.....                                                  | 2   |
| 2    | 045-0001-01  | Washer .....                                 | 4   | 25   | 051-0002-00 | Back Lock .....                                                        | 1   |
| 3    | 057-0436-00  | Lift Support Rod .....                       | 1   | 26   | 042-0003-00 | Cotter Pin.....                                                        | 1   |
| 4    | 051-0132-40  | Lift Lever .....                             | 1   | 27   |             | Back Support Rod Assembly (Refer to Table Top Components" Elsewhere).. | Ref |
| 5    | 025-0003-00  | Lift Spring.....                             | 2   | 28   | 040-0250-00 | Set Screw .....                                                        | 2   |
| 6    | 016-0008-00  | Eye Bolt.....                                | 2   | 29   | 057-0435-40 | Back Lock Rod .....                                                    | 1   |
| 7    | 045-0001-02  | Washer.....                                  | 2   | 30   | 030-0731-40 | Upper Wrap Weldment .....                                              | 1   |
| 8    | 041-0250-05  | Wing Nut .....                               | 2   | 31   | 030-1034-40 | Foot Rest Weldment.....                                                | 1   |
| 9    | 029-0305-06  | Cover Assy. (Right Hand Tables Only) .....   | 1   | 32   | 053-0828-00 | Foot Rest Trim .....                                                   | 1   |
|      | 029-0305-07  | Cover Assy. (Left Hand Tables Only) .....    | 1   | 33   | 053-0220-01 | Treatment Pan (Standard) .....                                         | 1   |
| 10   |              | Serial Number Label .....                    | Ref |      | 9A70000     | Stainless Steel Treatment Pan (Optional Accessory) .....               | 1   |
| 11   | 061-0291-00  | Patent Number Label .....                    | 1   | 34   | 041-0009-00 | Push Nut.....                                                          | 2   |
| 12   | 061-0620-00  | U.L./C.U.L. Label(Domestic Units).....       | 1   | 35   | 053-0018-00 | Nylon Tape (Listed In Inches) .....                                    | 52  |
|      | 061-0661-00  | CE Representative Label (Export Units) ..... | 1   | 36   | 053-0268-00 | End Cap (Units w/ Pelvic Lift Only).....                               | 2   |
| 13   | 040-0010-00  | Screw .....                                  | 12  | 37   | 057-0242-40 | Pelvic Lift Bar (Units w/ Pelvic Lift Only) .....                      | 1   |
| 14   | 050-0180-40  | End Cap .....                                | 1   | 38   | 016-0284-01 | R.H. Spring (Units on Left Side[Shown]) .....                          | 1   |
| 15   | 050-1651-40  | Lock Bracket (Left Hand Tables Only).....    | 1   |      | 016-0284-00 | L.H. Spring (Units on Left Side) .....                                 | 1   |
| 16   | 042-0010-03  | Pop Rivet.....                               | 4   | 39   | 040-0010-18 | Screw.....                                                             | 4   |
| 17   | 053-0014-00  | Self Sticking Bumper.....                    | 4   | 40   | 061-0652-00 | Type B Equipment Label (Export Units) .....                            | 1   |
| 18   | 053-0844-00  | R.H. Back Lock Handle.....                   | 1   | 41   | 061-0590-00 | CE Label (Export Units) .....                                          | 1   |
| 19   | 053-0844-01  | L.H. Back Lock Handle.....                   | 1   | 42   | 061-0654-00 | Caution Label(Export Units) .....                                      | 3   |
| 20   | 040-0250-148 | Set Screw.....                               | 2   | 43   | 061-0653-00 | Earth (Ground) Label (Export Units) .....                              | 1   |
| 21   | 040-0010-74  | Screw .....                                  | 1   |      |             |                                                                        |     |
| 22   | 045-0001-04  | Lockwasher .....                             | 1   |      |             |                                                                        |     |
| 23   | 050-0101-00  | .....Back Lock Spring Retainer.....          | 1   |      |             |                                                                        |     |

Always Specify Model & Serial Number

# Upper Wrap Components

## SECTION VI PARTS LIST



MA354102


Used on Units with Serial Numbers GJ4377 thru GJ8690, GK6755 thru GK13746, JE1348 thru JE1645, JF1094 thru JF1217, JG2278 thru JG3105, JH1217 thru JH1417 & LC1694 thru LC2452

| Item | Part No.     | Description                                 | Qty | Item | Part No.    | Description                                                            | Qty |
|------|--------------|---------------------------------------------|-----|------|-------------|------------------------------------------------------------------------|-----|
| 1    | 042-0159-00  | Retaining Ring.....                         | 2   | 23   |             | Screw.....                                                             | 2   |
| 2    | 045-0001-01  | Washer.....                                 | 2   | 24   | 042-0003-00 | Cotter Pin.....                                                        | 1   |
| 3    | 057-0436-00  | Lift Support Rod.....                       | 1   | 25   |             | Back Support Rod Assembly (Refer to Table Top Components" Elsewhere).. | Ref |
| 4    | 051-0132-40  | Lift Lever.....                             | 1   | 26   | 040-0250-00 | Set Screw.....                                                         | 2   |
| 5    | 025-0003-00  | Lift Spring.....                            | 2   | 27   | 057-0435-40 | Back Lock Rod.....                                                     | 1   |
| 6    | 016-0008-00  | Eye Bolt.....                               | 2   | 28   | 030-1286-40 | Upper Wrap Weldment.....                                               | 1   |
| 7    | 045-0001-02  | Washer.....                                 | 2   | 29   | 030-1034-40 | Foot Rest Weldment.....                                                | 1   |
| 8    | 041-0250-05  | Wing Nut.....                               | 2   | 30   | 053-0828-00 | Foot Rest Trim.....                                                    | 1   |
| 9    | 029-0305-06  | Cover Assy. (Right Hand Tables Only.....    | 1   | 31   | 053-0220-01 | Treatment Pan (Standard).....                                          | 1   |
|      | 029-0305-07  | Cover Assy. (Left Hand Tables Only.....     | 1   |      | 9A70000     | Stainless Steel Treatment Pan (Optional Accessory).....                | 1   |
| 10   |              | Serial Number Label.....                    | Ref | 32   | 041-0009-00 | Push Nut.....                                                          | 2   |
| 11   | 061-0291-00  | Patent Number Label.....                    | 1   | 33   | 053-0018-00 | Nylon Tape (Listed In Inches).....                                     | 52  |
| 12   | 061-0620-00  | U.L./C.U.L. Label(Domestic Units).....      | 1   | 34   | 053-0268-00 | End Cap (Units w/ Pelvic Lift Only).....                               | 2   |
|      | 061-0661-00  | CE Representative Label (Export Units)..... | 1   | 35   | 057-0242-40 | Pelvic Lift Bar (Units w/ Pelvic Lift Only).....                       | 1   |
| 13   | 040-0010-00  | Screw.....                                  | 14  | 36   | 016-0284-01 | R.H. Spring (Units on Left Side[Shown]).....                           | 1   |
| 14   | 050-0180-40  | End Cap.....                                | 1   |      | 016-0284-00 | L.H. Spring (Units on Left Side).....                                  | 1   |
| 15   | 042-0010-03  | Pop Rivet.....                              | 4   | 37   | 040-0010-18 | Screw.....                                                             | 4   |
| 16   | 053-0014-00  | Self Sticking Bumper.....                   | 4   | 38   | 061-0652-00 | Type B Equipment Label (Export Units).....                             | 1   |
| 17   | 053-0844-00  | R.H. Back Lock Handle.....                  | 1   | 39   | 061-0590-00 | CE Label (Export Units).....                                           | 1   |
| 18   | 053-0844-01  | L.H. Back Lock Handle.....                  | 1   | 40   |             | ddd.....                                                               | 1   |
| 19   | 040-0250-148 | Set Screw.....                              | 2   | 41   | 061-0654-00 | Caution Label(Export Units).....                                       | 3   |
| 20   | 050-4723-40  | Back Lock Spring Retainer.....              | 1   | 42   | 061-0653-00 | Earth (Ground) Label (Export Units).....                               | 1   |
| 21   | 051-0926-00  | Back Lock.....                              | 1   |      |             |                                                                        |     |
| 22   | 025-0063-00  | Back Lock Spring.....                       | 2   |      |             |                                                                        |     |

Always Specify Model & Serial Number

# Upper Wrap Components

## SECTION VI PARTS LIST



MA354102


Used on Units with Serial Numbers GJ8691, GK13747, GL1232, JE1646, JF1218, JG3106, JH1418 & LC2453 thru Present

| Item | Part No.     | Description                                 | Qty | Item | Part No.    | Description                                                            | Qty |
|------|--------------|---------------------------------------------|-----|------|-------------|------------------------------------------------------------------------|-----|
| 1    | 042-0159-00  | Retaining Ring.....                         | 2   | 23   |             | Screw.....                                                             | 2   |
| 2    | 045-0001-01  | Washer.....                                 | 2   | 24   | 042-0003-00 | Cotter Pin.....                                                        | 1   |
| 3    | 057-0436-00  | Lift Support Rod.....                       | 1   | 25   |             | Back Support Rod Assembly (Refer to Table Top Components" Elsewhere).. | Ref |
| 4    | 051-0132-40  | Lift Lever.....                             | 1   | 26   | 040-0250-00 | Set Screw.....                                                         | 2   |
| 5    | 025-0003-00  | Lift Spring.....                            | 2   | 27   | 057-0435-40 | Back Lock Rod.....                                                     | 1   |
| 6    | 016-0008-00  | Eye Bolt.....                               | 2   | 28   | 030-1498-40 | Upper Wrap Weldment.....                                               | 1   |
| 7    | 045-0001-02  | Washer.....                                 | 2   | 29   | 030-1034-40 | Foot Rest Weldment.....                                                | 1   |
| 8    | 041-0250-05  | Wing Nut.....                               | 2   | 30   | 053-0828-00 | Foot Rest Trim.....                                                    | 1   |
| 9    | 029-0305-06  | Cover Assy. (Right Hand Tables Only)....    | 1   | 31   | 053-0220-01 | Treatment Pan (Standard).....                                          | 1   |
|      | 029-0305-07  | Cover Assy. (Left Hand Tables Only).....    | 1   |      | 9A70000     | Stainless Steel Treatment Pan (Optional Accessory).....                | 1   |
| 10   |              | Serial Number Label.....                    | Ref | 32   | 041-0009-00 | Push Nut.....                                                          | 2   |
| 11   | 061-0291-00  | Patent Number Label.....                    | 1   | 33   | 053-0018-00 | Nylon Tape (Listed In Inches).....                                     | 52  |
| 12   | 061-0620-00  | U.L./C.U.L. Label(Domestic Units).....      | 1   | 34   | 053-0268-00 | End Cap (Units w/ Pelvic Lift Only).....                               | 2   |
|      | 061-0661-00  | CE Representative Label (Export Units)..... | 1   | 35   | 057-0242-40 | Pelvic Lift Bar (Units w/ Pelvic Lift Only).....                       | 1   |
| 13   | 040-0010-00  | Screw.....                                  | 14  | 36   | 016-0284-01 | R.H. Spring (Units on Left Side[Shown]).....                           | 1   |
| 14   | 050-0180-40  | End Cap.....                                | 1   |      | 016-0284-00 | L.H. Spring (Units on Left Side).....                                  | 1   |
| 15   | 042-0010-03  | Pop Rivet.....                              | 4   | 37   | 040-0010-18 | Screw.....                                                             | 4   |
| 16   | 053-0014-00  | Self Sticking Bumper.....                   | 4   | 38   | 061-0652-00 | Type B Equipment Label (Export Units).....                             | 1   |
| 17   | 053-0844-00  | R.H. Back Lock Handle.....                  | 1   | 39   | 061-0590-00 | CE Label (Export Units).....                                           | 1   |
| 18   | 053-0844-01  | L.H. Back Lock Handle.....                  | 1   | 40   |             | ddd.....                                                               | 1   |
| 19   | 040-0250-148 | Set Screw.....                              | 2   | 41   | 061-0654-00 | Caution Label(Export Units).....                                       | 3   |
| 20   | 050-4723-40  | Back Lock Spring Retainer.....              | 1   | 42   | 061-0653-00 | Earth (Ground) Label (Export Units).....                               | 1   |
| 21   | 051-0926-00  | Back Lock.....                              | 1   |      |             |                                                                        |     |
| 22   | 025-0063-00  | Back Lock Spring.....                       | 2   |      |             |                                                                        |     |

Always Specify Model & Serial Number

# Stirrup Components

## SECTION VI PARTS LIST



MA354200i


**Used On Units With Serial Number GJ1000 thru GJ7243, GK1000 thru GK10688, GL1000 thru GL1220, JE1000 thru JE1609, JF1000 thru JF1209, JG1000 thru JG3027, JH1000 thru JH1399, and LC1000 thru LC2294**

| Item | Part No.      | Description                                             | Qty | Item | Part No.    | Description                                                | Qty |
|------|---------------|---------------------------------------------------------|-----|------|-------------|------------------------------------------------------------|-----|
| 1    | 029-1397-02   | Stirrup Assembly (Includes Items 2 thru 6).....         | 2   | 8    | 050-1785-02 | Stirrup Guide Bracket .....                                | 2   |
| 2    | • 020-0181-30 | • Stirrup .....                                         | 1   | 9    | 040-0010-47 | Screw .....                                                | 2   |
| 3    | • 020-0182-30 | • Pivot Block.....                                      | 1   | 10   | 053-0387-00 | Pivot Boss .....                                           | 2   |
| 4    | • 042-0001-00 | • Roll Pin .....                                        | 2   | 11   | 053-0380-00 | Stirrup Guide .....                                        | 1   |
| 5    | • 040-0250-15 | • Set Screw .....                                       | 1   | 12   | 040-0010-00 | Screw .....                                                | 4   |
| 6    | • 051-0668-03 | • Horizontal Bar.....                                   | 1   | 13   |             | Upper Wrap (Refer to "Upper Wrap Assembly" Elsewhere)..... | Ref |
| 7    | 016-0400-00   | Stirrup Index Spring (Apply Lubricant #S006-0719) ..... | 2   | 14   | 061-0296-00 | Stirrup Label .....                                        | 1   |

**Always Specify Model & Serial Number**

# Stirrup Components

## SECTION VI PARTS LIST



MA605800i


**Used On Units With Serial Number GJ7244 thru GJ8690, GK10689 thru GK13746,  
GL1221 thru GL1231, JE1610 thru JE1645, JF1210 thru JF1217, JG3028 thru JG3105,  
JH1400 thru JH1417, and LC2295 thru LC2452**

| Item | Part No.      | Description                                                | Qty | Item | Part No.    | Description                                                   | Qty |
|------|---------------|------------------------------------------------------------|-----|------|-------------|---------------------------------------------------------------|-----|
| 1    | 029-2951-03   | Stirrup Assembly (Includes<br>Items 2 thru 4).....         | 2   | 7    | 050-5525-02 | Stirrup Guide Bracket.....                                    | 2   |
| 2    | • 020-0239-30 | • Stirrup.....                                             | 1   | 8    | 053-0387-00 | Pivot Boss .....                                              | 2   |
| 3    | • 042-0001-00 | • Roll Pin.....                                            | 1   | 9    | 053-0380-00 | Stirrup Guide .....                                           | 1   |
| 4    | • 051-1003-01 | • Stirrup Bar .....                                        | 1   | 10   | 040-0010-00 | Screw .....                                                   | 4   |
| 5    | 040-0010-47   | Screw.....                                                 | 2   | 11   |             | Upper Wrap (Refer to "Upper Wrap<br>Assembly" Elsewhere)..... | Ref |
| 6    | 016-0400-00   | Stirrup Index Spring (Apply Lubricant<br>#S006-0719) ..... | 2   | 12   | 061-0296-00 | Stirrup Label.....                                            | 1   |

**Always Specify Model & Serial Number**

# Stirrup Components

## SECTION VI PARTS LIST



MA605800i


**Used on Units with Serial Numbers GJ8691, GK13747, GL1232, JE1646, JF1218, JG3106, JH1418 & LC2453 thru Present**

| Item | Part No.      | Description                                             | Qty | Item | Part No.    | Description                                                | Qty |
|------|---------------|---------------------------------------------------------|-----|------|-------------|------------------------------------------------------------|-----|
| 1    | 029-2951-03   | Stirrup Assembly (Includes Items 2 thru 4).....         | 2   | 7    | 050-5525-02 | Stirrup Guide Bracket.....                                 | 2   |
| 2    | • 020-0239-30 | • Stirrup.....                                          | 1   | 8    | 053-0387-00 | Pivot Boss .....                                           | 2   |
| 3    | • 042-0001-00 | • Roll Pin .....                                        | 1   | 9    | 053-1391-00 | Stirrup Guide .....                                        | 1   |
| 4    | • 051-1003-01 | • Stirrup Bar .....                                     | 1   | 10   | 040-0010-00 | Screw .....                                                | 4   |
| 5    | 040-0010-47   | Screw .....                                             | 2   | 11   |             | Upper Wrap (Refer to "Upper Wrap Assembly" Elsewhere)..... | Ref |
| 6    | 016-0400-00   | Stirrup Index Spring (Apply Lubricant #S006-0719) ..... | 2   | 12   | 061-0296-00 | Stirrup Label .....                                        | 1   |

**Always Specify Model & Serial Number**

# Cabinet Components (120 VAC Units)

## SECTION VI PARTS LIST




MA354500

| Item | Part No.      | Description                                                    | Quantity | Item | Part No.      | Description                                      | Quantity |
|------|---------------|----------------------------------------------------------------|----------|------|---------------|--------------------------------------------------|----------|
| 1    |               | Upper Wrap (Refer to "Upper Wrap Assembly" Elsewhere).....Ref  |          | 17   | 015-0002-05   | Strain Relief Bushing.....                       | 1        |
| 2    | 061-0621-02   | Nameplate Label.....                                           | 1        | 18   | 015-0007-04   | Wrap-N-Tap Wire Clamp.....                       | 1        |
| 3    | 040-0010-00   | Screw.....                                                     | 18       | 19   | 030-1059-30   | Base Weldment.....                               | 1        |
| 4    | 050-3608-40   | Front Support Panel.....                                       | 2        | 20   | 041-0030-00   | Speed Nut.....                                   | 2        |
| 5    | 042-0010-03   | Pop Rivet.....                                                 | 5        | 21   | 053-0014-00   | Self Sticking Bumper.....                        | 2        |
| 6    | 016-0677-01   | Cabinet Member Foot Slide.....                                 | 2        | 22   | 016-0001-00   | Leveling Screw.....                              | 4        |
| 7    | 050-3607-40   | Center Support Panel.....                                      | 1        | 23   | 042-0010-01   | Pop Rivet.....                                   | 18       |
| 8    | 030-1035-40   | Back Weldment.....                                             | 1        | 24   | 050-3628-40   | Short Foot Mullion.....                          | 1        |
| 9    | 016-0676-01   | Cabinet Member Side Slide.....                                 | 3        | 25   | 050-3618-40   | Foot Mullion.....                                | 1        |
| 10   | 053-0004-00   | Glide.....                                                     | 10       | 26   | 002-0709-05   | Drawer Assy.- Foot (incl. item 15).....          | 2        |
| 11   | 050-3609-40   | End Panel.....                                                 | 1        | 27   | • 050-3685-00 | • Drawer Insert (Specify Color).....             | 2        |
| 12   | 050-3617-40   | Side Mullion.....                                              | 2        | 28   |               | Step Assembly (Refer to "Step Assembly").....Ref |          |
| 13   | 050-3715-40   | Side Mounting Bracket.....                                     | 1        | 29   | 053-0001-00   | Nylon Stem Bumper.....                           | 2        |
| 14   | 002-0709-04   | Side Drawer Assy. (incl. item 15).....                         | 3        | 30   | 061-0295-00   | Cord Tag.....                                    | 1        |
| 15   | • 050-3684-00 | • Drawer Insert (Specify Color).....                           | 3        |      |               |                                                  |          |
| 16   |               | Power Cord Assembly (Refer to "Electrical Components").....Ref |          |      |               |                                                  |          |

Always Specify Model &amp; Serial Number

# Cabinet Components (220 VAC Units)

## SECTION VI PARTS LIST




MA482200

| Item | Part No.      | Description                                                 | Quantity | Item | Part No.      | Description                                                                               | Quantity |
|------|---------------|-------------------------------------------------------------|----------|------|---------------|-------------------------------------------------------------------------------------------|----------|
| 1    |               | Upper Wrap (Refer to "Upper Wrap Assembly" Elsewhere) ..... | Ref      | 18   | 015-0007-04   | Wrap-N-Tap Wire Clamp.....                                                                | 1        |
| 2    | 061-0621-02   | Nameplate Label.....                                        | 1        | 19   | 030-1158-30   | Base Weldment .....                                                                       | 1        |
| 3    | 040-0010-00   | Screw.....                                                  | 18       | 20   | 041-0030-00   | Speed Nut.....                                                                            | 2        |
| 4    | 050-3608-40   | Front Support Panel.....                                    | 2        | 21   | 053-0014-00   | Self Sticking Bumper .....                                                                | 2        |
| 5    | 042-0010-03   | Pop Rivet .....                                             | 5        | 22   | 016-0001-00   | Leveling Screw .....                                                                      | 4        |
| 6    | 016-0677-01   | Cabinet Member Foot Slide .....                             | 2        | 23   | 042-0010-01   | Pop Rivet .....                                                                           | 18       |
| 7    | 050-3607-40   | Center Support Panel .....                                  | 1        | 24   | 050-3628-40   | Short Foot Mullion.....                                                                   | 1        |
| 8    | 030-1035-40   | Back Weldment.....                                          | 1        | 25   | 050-3618-40   | Foot Mullion .....                                                                        | 1        |
| 9    | 016-0676-01   | Cabinet Member Side Slide .....                             | 3        | 26   | 002-0709-05   | Drawer Assy.- Foot (incl. item 15).....                                                   | 2        |
| 10   | 053-0004-00   | Glide .....                                                 | 10       | 27   | • 050-3685-00 | • Drawer Insert (Specify Color) .....                                                     | 2        |
| 11   | 050-3609-40   | End Panel .....                                             | 1        | 28   |               | Step Assembly (Refer to "Step Assembly").....                                             | Ref      |
| 12   | 050-3617-40   | Side Mullion .....                                          | 2        | 29   | 053-0001-00   | Nylon Stem Bumper.....                                                                    | 2        |
| 13   | 050-3715-40   | Side Mounting Bracket.....                                  | 1        | 30   | 053-0068-00   | Snap Bushing (Units w/ Receptacle) .....                                                  | 1        |
| 14   | 002-0709-04   | Side Drawer Assy. (incl. item 15).....                      | 3        | 31   |               | Appliance Inlet Cover (Units w/o Receptacle)(Refer to "Receptacle Assembly [Export]"..... | 1        |
| 15   | • 050-3684-00 | • Drawer Insert (Specify Color) .....                       | 3        | 32   | 061-0662-00   | Fuse Replacement Label (Units w/ Receptacle).....                                         | 1        |
| 16   | 050-4153-00   | Appliance Inlet Enclosure (Units w/ Receptacle).....        | 1        |      |               |                                                                                           |          |
| 17   | 040-0010-47   | Screw.....                                                  | 2        |      |               |                                                                                           |          |

Always Specify Model &amp; Serial Number

# Step Assembly

## SECTION VI PARTS LIST




MA354301

| Item | Part No.      | Description                            | Quantity | Item | Part No.      | Description               | Quantity |
|------|---------------|----------------------------------------|----------|------|---------------|---------------------------|----------|
|      | 002-0709-06   | Step Assembly (incl. #1 thru #8) ..... | 1        | 5    | • 040-0006-00 | • Screw .....             | 8        |
| 1    | • 053-0848-00 | • Step Covering .....                  | 1        | 6    | • 053-0846-00 | • Step Stop .....         | 1        |
| 2    | • 030-1050-40 | • Step Weldment .....                  | 1        | 7    | • 053-0001-00 | • Nylon Stem Bumper ..... | 12       |
| 3    | • 053-0823-00 | • Foot Drawer Front .....              | 1        | 8    | • 053-0716-00 | • Bumper .....            | 2        |
| 4    | • 050-3685-00 | • Drawer Insert (Specify Color) .....  | 1        |      |               |                           |          |

Always Specify Model &amp; Serial Number

# Electrical Components (120 VAC Units)

## SECTION VI PARTS LIST



MA354400


**Used On Units With Serial Number GJ1000 thru GJ8690, GK1000 thru GK13746,  
GL1000 thru GL1231, JE1000 thru JE1645, JF1000 thru JF1217, JG1000 thru JG3105,  
JH1000 thru JH1417, and LC1000 thru LC2452**

| Item | Part No.    | Description                                                                   | Qty | Item | Part No.    | Description                                                                                                                                             | Qty |
|------|-------------|-------------------------------------------------------------------------------|-----|------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| 1    | 015-0007-04 | Wrap-N-Tap Wire Clamp .....                                                   | 3   | 14   | 053-0068-00 | Snap Bushing (Units w/ Heater Only) ....                                                                                                                | 1   |
| 2    | 053-0068-00 | Snap Bushing .....                                                            | 1   | 15   | 053-0068-01 | Snap Bushing (Units w/ Heater Only) ....                                                                                                                | 1   |
| 3    | 015-0066-03 | Power Cord Assembly .....                                                     | 1   | 16   | 053-0362-00 | Heat Shield (Units w/ Heater Only) .....                                                                                                                | 1   |
| 4    | 053-0068-07 | Snap Bushing .....                                                            | 1   | 17   | 002-0554-00 | Heater Plate Assembly-60 Watt (Includes<br>Items 16 and 18) (Units w/ Heater Only)<br>(Refer to "Wiring Diagram" {Section 5}<br>for Wire Numbers) ..... | 1   |
| 5    | 040-0010-47 | Screw .....                                                                   | 3   | 18   | 040-0010-35 | Screw (Units w/ Heater Only) .....                                                                                                                      | 2   |
| 6    | 053-0092-00 | Fishpaper Insulator .....                                                     | 1   | 19   | 015-0007-00 | Wrap-N-Tap Wire Clamp (Units w/<br>Heater Only) .....                                                                                                   | 1   |
| 7    | 015-0083-01 | Duplex Receptacle (Refer to "Wiring<br>Diagram [Section 5] for Wire Numbers . | 1   | 20   |             | Upper Wrap (Refer to "Upper Wrap<br>Assembly" Elsewhere) .....                                                                                          | Ref |
| 8    | 040-0006-13 | Screw .....                                                                   | 2   | 21   |             | Jumper Wire (Refer to "Wiring<br>Diagram {Section 5} for Wire Numbers)                                                                                  | 1   |
| 9    | 053-0836-00 | Receptacle Cover .....                                                        | 1   |      |             |                                                                                                                                                         |     |
| 10   | 040-0006-23 | Screw .....                                                                   | 1   |      |             |                                                                                                                                                         |     |
| 11   | 053-0350-02 | Heater Plug (Units w/o Heater Only) ....                                      | 1   |      |             |                                                                                                                                                         |     |
| 12   | 015-0650-00 | Heater Switch (Units w/ Heater Only) ...                                      | 1   |      |             |                                                                                                                                                         |     |
| 13   | 061-0294-00 | Caution Label (Units w/ Heater Only) ....                                     | 1   |      |             |                                                                                                                                                         |     |

**Always Specify Model & Serial Number**

# Electrical Components (120 VAC Units)

## SECTION VI PARTS LIST



MA354400


**Used on Units with Serial Numbers GJ8691, GK13747, GL1232, JE1646, JF1218,  
JG3106, JH1418 & LC2453 thru Present**

| Item | Part No.    | Description                                                                   | Qty | Item | Part No.    | Description                                                                                                                                             | Qty |
|------|-------------|-------------------------------------------------------------------------------|-----|------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| 1    | 015-0007-04 | Wrap-N-Tap Wire Clamp .....                                                   | 3   | 14   | 053-0068-10 | Snap Bushing (Units w/ Heater Only) ....                                                                                                                | 1   |
| 2    | 053-0068-00 | Snap Bushing.....                                                             | 1   | 15   | 053-0068-01 | Snap Bushing (Units w/ Heater Only) ....                                                                                                                | 1   |
| 3    | 015-0066-03 | Power Cord Assembly.....                                                      | 1   | 16   | 053-0362-00 | Heat Shield (Units w/ Heater Only) .....                                                                                                                | 1   |
| 4    | 053-0068-10 | Snap Bushing.....                                                             | 1   | 17   | 002-0554-00 | Heater Plate Assembly-60 Watt (Includes<br>Items 16 and 18) (Units w/ Heater Only)<br>(Refer to "Wiring Diagram" {Section 5}<br>for Wire Numbers) ..... | 1   |
| 5    | 040-0010-47 | Screw .....                                                                   | 3   | 18   | 040-0010-35 | Screw (Units w/ Heater Only) .....                                                                                                                      | 2   |
| 6    | 053-0092-00 | Fishpaper Insulator .....                                                     | 1   | 19   | 015-0007-00 | Wrap-N-Tap Wire Clamp (Units w/<br>Heater Only) .....                                                                                                   | 1   |
| 7    | 015-0083-01 | Duplex Receptacle (Refer to "Wiring<br>Diagram [Section 5] for Wire Numbers . | 1   | 20   |             | Upper Wrap (Refer to "Upper Wrap<br>Assembly" Elsewhere) .....                                                                                          | Ref |
| 8    | 040-0006-13 | Screw .....                                                                   | 2   | 21   |             | Jumper Wire (Refer to "Wiring<br>Diagram {Section 5} for Wire Numbers)                                                                                  | 1   |
| 9    | 053-0836-00 | Receptacle Cover.....                                                         | 1   |      |             |                                                                                                                                                         |     |
| 10   | 040-0006-23 | Screw .....                                                                   | 1   |      |             |                                                                                                                                                         |     |
| 11   | 053-0350-02 | Heater Plug (Units w/o Heater Only) ....                                      | 1   |      |             |                                                                                                                                                         |     |
| 12   | 015-0650-00 | Heater Switch (Units w/ Heater Only) ...                                      | 1   |      |             |                                                                                                                                                         |     |
| 13   | 061-0294-00 | Caution Label (Units w/ Heater Only) ....                                     | 1   |      |             |                                                                                                                                                         |     |

**Always Specify Model & Serial Number**

# Electrical Components (220 VAC Units)

## SECTION VI PARTS LIST



MA482300


**Used On Units With Serial Number GJ1000 thru GJ8690, GK1000 thru GK13746,  
GL1000 thru GL1231, JE1000 thru JE1645, JF1000 thru JF1217, JG1000 thru JG3105,  
JH1000 thru JH1417, and LC1000 thru LC2452**

| Item | Part No.    | Description                                                                                           | Qty | Item | Part No.    | Description                                                       | Qty |
|------|-------------|-------------------------------------------------------------------------------------------------------|-----|------|-------------|-------------------------------------------------------------------|-----|
| 1    | 015-0007-04 | Wrap-N-Tap Wire Clamp .....                                                                           | 3   | 15   | •           | • Cord Set .....                                                  | 1   |
| 2    | 053-0068-00 | Snap Bushing.....                                                                                     | 1   | 16   | 053-0350-02 | Heater Plug (Units w/o Heater Only) ....                          | 1   |
| 3    |             | Appliance Inlet Harness (Refer to<br>"Wiring Diagram" [Section 5] for<br>Wire Numbers .....           | 1   | 17   | 015-0650-00 | Heat Switch (Units w/ Heater Only) .....                          | 1   |
| 4    |             | Receptacle Assembly (Includes Items 5<br>thru 15) (Refer to "Receptacle<br>Assembly" Elsewhere) ..... | 1   | 18   | 061-0676-00 | Multinational Heater Switch Label<br>(Units w/ Heater Only) ..... | 1   |
| 5    | •           | • Screw .....                                                                                         | 2   | 19   | 053-0068-00 | Snap Bushing (Units w/ Heater Only) ....                          | 1   |
| 6    | •           | • Snap Bushing.....                                                                                   | 1   | 20   | 053-0068-01 | Snap Bushing (Units w/ Heater Only) ....                          | 1   |
| 7    | •           | • Lock Washer .....                                                                                   | 2   | 21   | 029-1222-01 | Heater Plate Assembly - 50 Watt<br>(Units w/ Heater Only) .....   | 1   |
| 8    | •           | • Jumper Wire.....                                                                                    | 1   | 22   | 053-0362-00 | Heat Shield (Units w/ Heater Only) .....                          | 1   |
| 9    | •           | • Screw .....                                                                                         | 2   | 23   | 040-0010-35 | Screw (Units w/ Heater Only) .....                                | 2   |
| 10   | •           | • Fishpaper .....                                                                                     | 1   | 24   | 015-0007-00 | Wrap-N-Tap (Units w/ Heater Only) .....                           | 4   |
| 11   | •           | • Nutsert .....                                                                                       | 2   | 25   |             | Upper Wrap (Refer to "Upper Wrap<br>Assembly" Elsewhere .....     | 1   |
| 12   | •           | • Receptacle Cover .....                                                                              | 1   | 26   | 061-0654-00 | Caution Label (Units w/ Receptacle) ....                          | 1   |
| 13   | •           | • Bezel .....                                                                                         | 1   | 27   | 061-0650-00 | Dangerous Voltage Label<br>(Units w/ Receptacle).....             | 1   |
| 14   | •           | • Export Receptacle (UK shown).....                                                                   | 1   |      |             |                                                                   |     |

**Always Specify Model & Serial Number**

# Electrical Components (220 VAC Units)

## SECTION VI PARTS LIST



MA482300


**Used on Units with Serial Numbers GJ8691, GK13747, GL1232, JE1646, JF1218, JG3106, JH1418 & LC2453 thru Present**

| Item | Part No.    | Description                                                                                           | Qty | Item | Part No.    | Description                                                       | Qty |
|------|-------------|-------------------------------------------------------------------------------------------------------|-----|------|-------------|-------------------------------------------------------------------|-----|
| 1    | 015-0007-04 | Wrap-N-Tap Wire Clamp .....                                                                           | 3   | 15   | •           | • Cord Set .....                                                  | 1   |
| 2    | 053-0068-10 | Snap Bushing.....                                                                                     | 1   | 16   | 053-0350-02 | Heater Plug (Units w/o Heater Only) .....                         | 1   |
| 3    |             | Appliance Inlet Harness (Refer to<br>"Wiring Diagram" [Section 5] for<br>Wire Numbers .....           | 1   | 17   | 015-0650-00 | Heat Switch (Units w/ Heater Only) .....                          | 1   |
| 4    |             | Receptacle Assembly (Includes Items 5<br>thru 15) (Refer to "Receptacle<br>Assembly" Elsewhere) ..... | 1   | 18   | 061-0676-00 | Multinational Heater Switch Label<br>(Units w/ Heater Only) ..... | 1   |
| 5    | •           | • Screw .....                                                                                         | 2   | 19   | 053-0068-10 | Snap Bushing (Units w/ Heater Only) ....                          | 1   |
| 6    | •           | • Snap Bushing.....                                                                                   | 1   | 20   | 053-0068-01 | Snap Bushing (Units w/ Heater Only) ....                          | 1   |
| 7    | •           | • Lock Washer .....                                                                                   | 2   | 21   | 029-1222-01 | Heater Plate Assembly - 50 Watt<br>(Units w/ Heater Only) .....   | 1   |
| 8    | •           | • Jumper Wire.....                                                                                    | 1   | 22   | 053-0362-00 | Heat Shield (Units w/ Heater Only) .....                          | 1   |
| 9    | •           | • Screw .....                                                                                         | 2   | 23   | 040-0010-35 | Screw (Units w/ Heater Only) .....                                | 2   |
| 10   | •           | • Fishpaper .....                                                                                     | 1   | 24   | 015-0007-00 | Wrap-N-Tap (Units w/ Heater Only) .....                           | 4   |
| 11   | •           | • Nutsert .....                                                                                       | 2   | 25   |             | Upper Wrap (Refer to "Upper Wrap<br>Assembly" Elsewhere .....     | 1   |
| 12   | •           | • Receptacle Cover .....                                                                              | 1   | 26   | 061-0654-00 | Caution Label (Units w/ Receptacle) ....                          | 1   |
| 13   | •           | • Bezel.....                                                                                          | 1   | 27   | 061-0650-00 | Dangerous Voltage Label<br>(Units w/ Receptacle).....             | 1   |
| 14   | •           | • Export Receptacle (UK shown).....                                                                   | 1   |      |             |                                                                   |     |

**Always Specify Model & Serial Number**

# Receptacle Assembly (220 VAC Units)

## SECTION VI PARTS LIST



MA482400

| Item | Part No.      | Description                                                                  | Quantity | Item | Part No.      | Description                                                                                                              | Quantity |
|------|---------------|------------------------------------------------------------------------------|----------|------|---------------|--------------------------------------------------------------------------------------------------------------------------|----------|
|      | 9A234001      | Receptacle Assembly - Belgium<br>(Includes Items 1 thru 11).....             | 1        | 5    | • 015-0704-00 | • Receptacle Bezel .....                                                                                                 | 1        |
|      | 9A234002      | Receptacle Assembly - Europe<br>(Includes Items 1 thru 11).....              | 1        | 6    | • 015-0068-07 | • Snap Bushing.....                                                                                                      | 1        |
|      | 9A234003      | Receptacle Assembly - United Kingdom<br>(Includes Items 1 thru 11).....      | 1        | 7    | • 015-0547-01 | • Jumper Wire.....                                                                                                       | 1        |
|      | 9A234004      | Receptacle Assembly - Italy<br>(Includes Items 1 thru 11).....               | 1        | 8    | • 040-0010-47 | • Screw .....                                                                                                            | 2        |
|      | 9A234006      | Receptacle Assembly - Australia<br>(Includes Items 1 thru 11).....           | 1        | 9    | • 042-0045-01 | • Nutsert.....                                                                                                           | 2        |
|      | 9A234007      | Receptacle Assembly - No Receptacle<br>(Includes Items 1, 9, 10 and 12)..... | 1        | 10   | • 050-4162-40 | • Receptacle Cover w/ Cutout<br>(Units w/ receptacle) .....                                                              | 1        |
| 1    | • 040-0010-34 | • Screw2                                                                     |          |      | • 050-4162-41 | • Receptacle Cover w/o Cutout<br>(Units w/o receptacle) .....                                                            | 1        |
| 2    | • 045-0001-31 | • Lockwasher .....                                                           | 2        | 11   | • 015-0363-00 | • Cordset - Belgium / Europe.....                                                                                        | 1        |
| 3    | • 053-0092-00 | • Fishpaper Insulator .....                                                  | 1        |      | • 015-0363-01 | • Cordset - Italy.....                                                                                                   | 1        |
| 4    | • 015-1294-00 | • Receptacle - Europe .....                                                  | 1        |      | • 015-0363-03 | • Cordset - United Kingdom.....                                                                                          | 1        |
|      | • 015-1294-01 | • Receptacle - Belgium .....                                                 | 1        |      | • 015-0363-04 | • Cordset - Australia .....                                                                                              | 1        |
|      | • 015-1294-02 | • Receptacle - United Kingdom (Shown)1                                       |          | 12   | • 050-4152-00 | • Appliance Inlet Cover (Not Shown -<br>Refer to "Cabinet Components [Export]"<br>Elsewhere) (Units w/o Receptacle)..... | 1        |
|      | • 015-1294-03 | • Receptacle - Italy .....                                                   | 2        |      |               |                                                                                                                          |          |
|      | • 015-1294-05 | • Receptacle - Australia.....                                                | 1        |      |               |                                                                                                                          |          |

Always Specify Model &amp; Serial Number

## COMMENTS

The Technical Publications Department of Midmark Corporation takes pride in its publications. We are sure that our manuals will fill all of your needs when you are performing scheduled maintenance, servicing, or repairs on a Midmark product.

However, if you find any errors or feel that there should be a change, addition, or deletion to a manual, please let us know!

**Page(s) and Paragraph(s) Needing Changed:**

**Description of Error or Desired Change:**

Please fax or mail a copy of this completed comment sheet to:

Midmark Corporation  
ATTN: Technical Publications Department  
60 Vista Drive  
Versailles, Ohio 45380  
Fax: (937) 526-5542

## FAX ORDERING FORM

**(SERVICE PARTS ONLY)**

**NOTES:**

- ALL **BLOCKED** AREAS MUST BE COMPLETED.
- USE FOR NON-WARRANTY FAX ORDERS ONLY. WARRANTY ORDERS MUST BE TELEPHONED IN (1-800-MIDMARK).

|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|------------------|
| ATTENTION: SERVICE DEPARTMENT FAX#: 877-249-1793                                                                                                                                                                                             |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
| ACCT #: _____                                                                                                                                                                                                                                |               | P.O. #: _____                                                                                                                                                                                                                                                                                                         |                       | DATE: _____      |
| NAME: _____                                                                                                                                                                                                                                  |               | SHIP TO: _____                                                                                                                                                                                                                                                                                                        |                       |                  |
| ADDRESS: _____                                                                                                                                                                                                                               |               | _____                                                                                                                                                                                                                                                                                                                 |                       |                  |
| CITY, ST.: _____                                                                                                                                                                                                                             |               | _____                                                                                                                                                                                                                                                                                                                 |                       |                  |
| CONTACT: _____                                                                                                                                                                                                                               |               | _____                                                                                                                                                                                                                                                                                                                 |                       |                  |
| PHONE: _____                                                                                                                                                                                                                                 |               | _____                                                                                                                                                                                                                                                                                                                 |                       |                  |
| <input type="checkbox"/> NON-EMERGENCY ORDER - TO SHIP WITHIN 72 HOURS IF PART(S) IN STOCK.<br>_____                                                                                                                                         |               | <b>METHOD OF SHIPMENT</b> <u>OTHER</u> _____                                                                                                                                                                                                                                                                          |                       |                  |
| <input type="checkbox"/> EMERGENCY ORDER - TO SHIP WITHIN 24 HOURS IF PART(S) IN STOCK (IF ORDER IS RECEIVED BEFORE 1:30 P.M. E.S.T).<br>SEND NOTIFICATION IF PARTS ARE NOT AVAILABLE TO SHIP WITHIN 24 HOURS VIA<br>E-MAIL OR FAX TO: _____ |               | <b>UPS</b><br><input type="checkbox"/> NEXT DAY A.M. <input type="checkbox"/> NEXT DAY A.M.<br><input type="checkbox"/> NEXT DAY P.M. <input type="checkbox"/> NEXT DAY P.M.<br><input type="checkbox"/> 2ND DAY <input type="checkbox"/> 2ND DAY<br><input type="checkbox"/> GROUND <input type="checkbox"/> ECONOMY |                       |                  |
| <b>QTY.</b>                                                                                                                                                                                                                                  | <b>PART #</b> | <b>DESCRIPTION</b> (SPECIFY COLOR OF ITEM IF APPLICABLE)                                                                                                                                                                                                                                                              | <b>COLOR CODE</b>     | <b>PRICE/PER</b> |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       |                       |                  |
|                                                                                                                                                                                                                                              |               |                                                                                                                                                                                                                                                                                                                       | <b>TOTAL COST: \$</b> |                  |



Midmark Corporation  
60 Vista Drive  
P.O. Box 286  
Versailles, Ohio 45380-0286  
937-526-3662  
Fax 937-526-5542  
midmark.com



Because we care.

Subject To Change Without Notice